


Quattro Chair

Assembly Instructions - Please keep for future reference

814/3859

760/7286

habitat 



Dimensions

Width - 52cm

Depth - 49cm

Height - 71cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 640 0800



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- Unit weight: 4.2 kgs.
- Maximum safe weight of user: 110kgs.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- Always lift the product when moving it around. Never drag.
- Do not stand on the product.
- Do not use this product as step ladder.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightend properly.


Components - Parts

If you have damaged or missing components, call the **Customer Helpline: 0345 640 0800**


Please check you have all the parts listed below



1 Seat



2 Upper Leg





3 Lower Leg


Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>M6 x 50mm Bolt</p>	<p>B </p> <p>M6 x 65mm Bolt x 4</p>	<p>C </p> <p>Spring washer x 5</p>
<p>D </p> <p>Washer x 5</p>	<p>E </p> <p>Allen key x 1</p>	<p>F </p> <p>Foot pad x 4</p>

Ruler - Use this ruler to help correctly identify the screws





Assembly Instructions

Step 1

Assembling legs

Attach the upper leg **3** to the lower leg **2** as shown and fix through holes using bolt **A**, spring washer **C** and flat washer **D**. Tighten the bolt using allen key **E**.





Step 2

Assembling the seat

Place the seat **1** face down on a flat protected surface.

Position the legs **2** & **3** on the seat then align and fix through holes using bolts **A**, spring washers **C** and flat washers **D**. Tighten the bolts using allen key **E**.




Assembly Instructions


Step 3

Attaching foot pads

Remove backing from foot pads **F** and carefully position on the bottom of the legs **2** & **3** as shown.



Carefully turn the chair upright after assembly.



Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 640 0800