




**IMPORTANT! RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCES.
ASSEMBLY TO BE CARRIED OUT BY A COMPETENT ADULT ONLY.**




PART LIST




① x2




② x1




③ x4




④ x1




⑤ x1




⑥ x1




⑦ x1




⑧ x1




⑨ x4




⑩ x1



⑪ x1



⑫ x1



⑬ x1

HARDWARE



A x10



B x10



C x14



D x2



E x18



F x14



G x14

TOOLS REQUIRED (not supplied)



**Phillips Head
Screw Driver**



**Flat Head
Screw Driver**







**Drill
+ 6mm Drill Bit**








Hammer


Step 1








Step 2








 <p>B x4</p>	 <p>C x4</p>	 <p>E x6</p>
---	---	---




 F x3	 C x2	 E x2	 G x3
--	--	--	---








	
C x2	F x4
	
G x4	E x2





Step 6





Step 7




B



Step 8



COMPLETE



CARE/CLEANING INSTRUCTIONS

- Wipe furniture with a soft dry cloth, do not use paper as this may be abrasive to the finish.
- The unit should be cleaned with a damp cloth and dried with a dry cloth.
- DO NOT use bleach or chemical solutions to clean the product.
- DO NOT expose to sunlight or other heat sources for a prolonged period.
- DO NOT store or leave outside.
- Periodically check the tightening of legs and screws.

SAFETY TESTED

The product conforms to: FIRA FRQG C001:2021 / FIRA FRQG C004:2016+A1:2017

WARNINGS

1. **WARNING: DO NOT** place this product near a window, as it can be used as a step by a child and cause the child to fall out of the window.
2. **WARNING: DO NOT** place this product near a window where the cords from blinds or curtains may strangle a child.
3. **WARNING: DO NOT** use this product if any part is broken, torn or missing. Please contact your supplier and spare parts can be supplied – please use only parts approved by the manufacturer.
4. **WARNING:** Be aware of the risk of open fires and other sources of strong heat in the vicinity of the product.
5. **WARNING:** Serious or fatal crush injuries can occur from furniture tip over. **ALWAYS** secure this unit to wall with wall fixings supplied.
6. Please keep children away from the work area during assembly of this product – due to risk of injury and small parts.
7. Once assembled, this product is **NOT** designed to be dismantled, and reassembled.
8. Dispose of all packaging carefully and responsibly.
9. We advise you to keep these instructions in a safe place in case required for future use.
10. Assembly to be carried out by a competent adult only.
11. Do not use this item if any components are missing or damaged.
12. This product is suitable for children aged 3-6 years.
13. The maximum loading weight of the product is 15 KG.
14. Regular check all fastenings to ensure that they are properly tightened.