
Foldable Clothes Rail



Spare Parts



www.argos-support.co.uk Help@ClickSpares.co.uk

0370 112 1928

△ Safety and CareAdvice

Product Details

Foldable Clothes Rail 7632677

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- This product has been constructed to be used in the domestic environment only and not for commercial purposes.

Care and maintenance

• Only clean using a damp cloth and mild detergent. Do not use abrasive cleaners.

• From time to time check that there are no loose screws, nuts or bolts. If there are please re-tighten.

- Use a dry cloth to clean the product, furniture polish is not recommended.

Additional Guidance

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tightened the bolts.
- Regularly check and ensure that all bolts and fittings are tightened properly.
- Maximum loading weight for Rail : 25 kgs

lssue1-01/12/22

Customer Support

0345 640 2020

 Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.



• We do not recommend the use of power drill/drivers for inserting screws


as this could damage the unit. Only use hand screwdrivers.

• Parts of the assembly will be easier with 2 people.

• Dispose of all packaging carefully and responsibly.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Fittings



3 Upper Steel Tube x 1 (Dia 1" x 0.35 x 880 mm)

4 Steel Tube x 2 (Dia 22 x 0.35 x 780 mm)

