


# Henri



## Spare Parts

-  [www.argos-support.co.uk](http://www.argos-support.co.uk)
-  [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk)
-  0370 112 1928

## Customer Support

-  0345 640 2020



# Safety and Care Advice

---

## Product Details

HENRI 5 DRW TALLBOY 7663969

## IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.


- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- This product has been constructed to be used in the domestic environment only and not for commercial purposes.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor.



- We do not recommend the use of power drill/drivers for inserting screws as this could damage the unit. Only use hand screwdrivers.

- Parts of the assembly will be easier with 2 people.

- Dispose of all packaging carefully and responsibly.

## Care and maintenance

---

- Only clean using a damp cloth and mild detergent. Do not use abrasive cleaners.

- Use a dry cloth to clean the product, furniture polish is not recommended.

- From time to time check that there are no loose screws, nuts or bolts. If there are please re-tighten.

- Reapply linseed oil every year.

- Allow to absorb for 1-2 hours and wipe dry.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

## Additional Guidance

---

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.

- Regularly check and ensure that all bolts and fittings are tightened properly.

- This product is suitable for adult and children from 3 to 12 years old.

- This product is compliant BS 4875-7, EN 14749, FIRA FRQG C001, FIRA FRQG C004.

- Any additional or replacement parts are obtained from the Clickspares.

## WARNING

---


- Assembly to be carried out by a competent adult only.

- During assembly children should be kept away from the product due to possible risk of injury.

- Do not use this item if any components are missing or damaged.

# Fittings (Shown to scale)

## Bag 1




# Tools required


---




Phillips screwdriver  
(small & medium)



Ruler/tape  
measure




Phillips screwdriver  
(small & medium)




Eye protection  
(when using a  
hammer or glue)




Small  
hammer




Large hammer



Power Drill




Pencil



Mallet



Drill Heads



Set Square

# Panels

---



**1** Top panel x 1  
(500 x 450mm)



**2** Left side panel x 1  
(1113 x 449mm)



**3** Right side panel x 1  
(1113 x 449mm)



**4** Bottom panel x 1  
(500 x 450mm)



**5** Back rail x 2  
(468 x 80mm)



**6** Back panel x 2  
(1142 x 248mm)



**7** Feet x 4  
(90 x 45mm)




**8** Brawer face x 1  
(462 x 219mm)




**9** Brawer face x 2  
(462 x 219mm)



**10** Brawer face x 1  
(462x 219mm)



**11** Brawer face x 1  
(462 x 219mm)



**12** Left drawer side x 5  
(400 x 174mm)

# Panels

---



**13** Right drawer side x 5  
(400 x 174mm)



**14** Drawer back x 5  
(424 x 174mm)



**15** Drawer bottom x 5  
(431 x 394mm)






**16** Drawer bottom support x 5  
(387 x 40mm)






**17** Plastic Strip x 1  
(1112mm)





# 1






# 2



# 3








# 4








# 5



# 6



# 7

**E**



35mm Screw x 2

**I**



Wall Anchor x 2





## WARNING!

In order to prevent overturning this product must be used with the wall attachment device provided. Serious or fatal crushing injuries can occur from furniture tipping over. To help prevent topple over :-

- Use the wall attachment devices provided
- Never allow children to climb or hang on drawers
- Do not overload the drawer beyond maximum recommended loading.
- Place heaviest items in the lower drawers or shelves.
- Unless specifically designed to accommodate, do not set TV's or other heavy objects on top of this product
- Never open more than one drawer at a time


An attachment device is provided with your product, however you will need to source suitable fixings for your wall type. If in doubt consult a qualified trades person.

Always ensure that the wall to be drilled into is free from hidden electrical wires, water and gas pipes.




## WARNING!

IN ORDER TO PREVENT OVERTURNING  
THIS PRODUCT MUST BE USED WITH  
THE WALL ATTACHMENT DEVICE  
PROVIDED



# 8

**B**




35mm Male Camlock x 25

**C**




Female Camlock x 25

**D**



35mm Screw x 25

**M**




30mm Dowel x 10


**L**





Sticker X 20







x5






x5





x2



x2



# 9



# A Guide to Wall Mounting & Fixings

## Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.



**Important:** When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


## Hints:

- 1: General rule: Always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

## Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

### No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

### No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

### No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

### No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

### No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

### No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satellite dishes etc.



## Care & Maintenance

**Safety:** Always check the fitting and location to ensure your safety in and around the home.

**Fitting:** From time to time check the fitting to ensure the wall plugs or screws do not become loose.