

Maintenance

Designed for indoor use only. Do not use polish or abrasive cleaner - just a soft dry cloth.


This unit is a Class III product - to be supplied from a SELV (Safety Extra-Low Voltage) power source. Power adapter is not included.
LED Light Source: 2W LED (non-user replaceable)
Charging input: 5VDC MAX 3A(15W)
Battery operated (Non replaceable)

Specification

Battery Capacity: 2200mAh, 8.14Wh (rechargeable lithium-ion)
Battery output voltage: 3.7V DC
Running time: Est. 8hrs on the highest brightness, 80hrs on the lowest brightness
Colour rendering index (CRI): >80
Colour Temperature: 3000K
Adjustable Brightness: 20/50/100 Lumen
Recommend power adapter (not provided): 5VDC 3A 15W
Charging time: 4hrs with provided USB-C cable and recommend power adapter
USB- C cable length: 1m
Note: The lamp cannot be used while charging and will stop once fully charged.

Recycling electrical products

You should now recycle your waste electrical goods and in doing so help the environment. This symbol means an electrical product should not be disposed of with normal household waste. Please ensure it is taken to a suitable facility for disposal.
Visit www.recycle-more.co.uk, click on “bank locator” and enter your postcode to find your nearest recycling site.




If you require any further assistance, you can contact us on 0345 640 2020 or visit habitat.co.uk/help/contact-us	Made in China Habitat, Argos Limited, London, EC1M 6HA, UK. <u>Argos (N.I.) Ltd</u> , Forestside Shopping Centre, Upper Galwally, Belfast, BT8 6FX, UK.
---	---



habitat

Hibberd Portable Lamp

7681790 & 146429731



Care & Instruction Manual

For household and indoor use only


Please read and retain these instructions for future reference

Important


- Read these instructions carefully and familiarize yourself with the procedure before assembling the unit.
- Take all the components and fittings out of the plastic bag and separate them into their groups.
- Ensure you have enough space to lay out all the parts before assembly.
- To avoid scratching it is recommended that you assemble the unit on a soft level surface.
- If the external flexible cable or cord of this luminaire is damaged, it shall be replaced by a special cord or cord exclusively available from the manufacturer or his service agent.
- The luminaire is designed for indoor use only.
- The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.
- This product is suitable for use by adults only. It is not a toy, please keep away from children.
- The product is not suitable for use with dimmer switch.
- The product should not be used close to sources of naked flames or heat.
- This product contains built-in batteries that are non-replaceable. Do not open and disassemble device. For battery recycling please dispose according to local environmental regulations.

Components


a. Glass shade



b.Lamp body



c.USB- C cable




d.Charger (this is not included. Suggest using 5V DC 3A output USB-C Power Adapter)

This product does not include a power adapter. Included in the pack is a USB-C charge cable that supports charging and is compatible with USB-C power adapters.

It shall be used with LED driver certified with related standard 60335-2-29 (IP20 or better, SELV , fail safe or short circuit proof; output: constant voltage type, 5 VDC; rating output wattage not less than loaded product's wattage, plug used in LED driver must be complied with local plug and socket regulation.)

Instruction for use

1. Screw in the glass shade onto the top the base.
2. Always fully charge a device before its first use.




This product is powered by a built-in rechargeable battery. The battery is recharged while you connect to power adapter; however, it will become totally discharged if you do not use the product for a long period of time. To recharge the built-in battery, connect the power adapter to the product and leave it connected for at least 4 hours with the light off.

The lamp goes off while charging and the battery will not charge while the lamp is on. The charge indicator lamp turns RED whiling charging, and it will goes WHITE when charging is completed.

Instruction of disassembling the battery for disposal

Please follow below step to remove the battery for disposal when the product is end of life.

1. Remove the felt pad under the base.
2. Remove the screws and metal plate.
3. Remove the screw and base.
4. Unplug the electrical wire and remove the battery for disposal.



Environmental Notice

Product contains batteries and/or recyclable electric waste. For environment protection do not dispose in household waste, but for recycling take to electric waste collection points provided in your country.