



Quick Start Guide



2-in-1 Interactive Bath Seat

VTECH

PO Box 10042, 6000 GA Weert, The Netherlands

Napier Court, Abingdon, OX14 3YT, UK

By reducing the quantity of paper used for our Parent's Guide/Manuals, we aim to reduce our environmental impact and contribute to the preservation of the environment. The full version of the Parent's Guide/Manual is available online through the following links or by scanning the QR code.



For UK
vtech.co.uk/manuals



For AUS/NZ
vtech.com.au/support/product_manuals

DANGER - Your child can drown if left alone

WARNING

IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

WARNING - Not a safety device.

WARNING - DROWNING HAZARD.

- Children have drowned while using bathing aids.
- Children can drown in very shallow water (2 cm) in a very short time.
- Always stay in touch with your child while bathing.
- Keep your child in your hand at all times.
- Never leave your baby unattended in the bath, even for a short time. If you have to leave the room, take your baby with you.
- DO NOT allow other children (even older ones) to substitute for an adult.

WARNING

- To avoid scalding from hot water, position the product so that the child cannot reach the source of water.
- Always ensure the suction cups are well adhered to the bath tub.
- Do not use this product in a bathtub with a non-slip surface.
- Always ensure the attachment device(s) are correctly fitted to the bath tub.
- Only use this product when your child is able to sit up unaided.
- Stop using this product when your child tries to stand up on their own.
- Check the temperature of the water around the product before placing the child inside it. The normal water temperature for bathing a child is between 35°C and 38°C.
- Check the stability of the product before using it.
- Do not use the product if some of its elements are broken or missing.
- Do not use spare parts other than those recommended by the manufacturer or distributor.
- Recommendations for cleaning and maintenance, if applicable.
- Make sure that the water level does not exceed the height of your child's navel.

INCLUDED IN THE PACKAGE




1 Chair Back



1 Seat



1 Activity Board



4 Suction Cups



1 Seal



1 Frog

- Quick Start Guide

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE


Please save this Quick Start Guide as it contains important information.

This electronic toy is intended for use in the bath and is waterproof when used as intended. Water cannot enter the electronics if the battery compartment door is locked correctly. The design is verified by submerging the toy underwater to a depth of 15cm for 30 minutes. There will be a reduction in acoustic performance when the toy is submerged in water.

GETTING STARTED

BATTERY REMOVAL AND INSTALLATION

1. Make sure the unit is turned OFF.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw. Then remove the cover.
3. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
4. Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box.
(For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

VTech® cares for the planet.

Care for the environment and give your toy a second life by disposing of it at a small electricals collection point so all its materials can be recycled.

In the UK:

Visit www.recyclenow.com to see a list of collection points near you.

In Australia & New Zealand:





Check with your local council for kerbside collections.

ASSEMBLY INSTRUCTIONS


CAUTION:

TO ENSURE YOUR CHILD'S SAFETY, THIS PRODUCT MUST BE ASSEMBLED BY AN ADULT.

1. Attach the suction cups by pushing them firmly into the 4 holes on the underside of the seat. Please adjust the suction cups according to requirement and ensure the cups are attached securely. Once the suction cups have been attached they cannot be removed again.
2. Attach the chair back by pushing it into the holes on either side of the seat, press gently until you hear it click into place. Please ensure the seat back is attached securely. Once the seat back has been attached, it cannot be removed again.
3. Attach the frog by placing it into the centre of the activity board. Press gently until you hear it click into place. Please ensure the frog is attached securely to the activity board, once the frog has been attached, it cannot be removed again.
4. To attach the activity board turn the release lock located on the bottom of the seat. Insert the board onto the lock, push down, then release the lock. To remove the activity board turn the lock again to release, then pull the activity board away from the seat.




Note : Once the bath seat is attached to the bath, loosen the suction cups before attempting to remove.



WARNINGS

- The batteries must be changed by an adult.
- Recommended bath length: 10 minutes.
- This toy cannot be used in salt water.
- After using this toy, do not leave it in the water for a long time.
- This toy can be operated in water only when fully assembled in accordance with the instructions.
- This is not a lifesaving device. Do not leave a child unattended while the **VTech® 2-in-1 Interactive Bath Seat** is in use.
- Never leave a child unattended or with an older child in the bathroom or in the bath, not even for one minute.
- Always check with a thermometer the temperature of the water coming from the tap before sitting the child in the bath. Toddlers have very sensitive skin and can easily get burnt if the water is too hot.
- Please keep your child away from the tap.
- Children's most vulnerable stage is 5-10 months.
- When closing the battery cover ensure that the screw is securely tightened. This will avoid any water leakage.
- Only use this unit in water between 10 and 45 degrees centigrade, Recommended bath water temperature: 37°C.
- Please keep the water depth to around 100 mm as marked on the legs of the bath seat.
- Always keep the child within arm's reach.



- During bath time stay in the room, do not answer the door or the phone, if you must leave the room for urgent reasons take your child with you.
- Please note the product does not provide any additional safety protection from water hazards or drowning.
- Correct position:



CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.
5. When taking a bath, the speaker may fill up with water temporarily and the volume of the product may decrease. Allow the water to drain away from the speaker or keep the speaker away from the water to recover its sound level.
6. If the unit is not working properly, install a brand new set of batteries.

Contact VTech

Tel: 0330 678 0149 (from UK)
 +44 330 678 0149 (outside UK)
 1800 862 155 (Aus) / 0800 400 785 (NZ)
www.vtech.co.uk
www.vtech.com.au