


# Clothes Hanger Stand

# Home.



## Spare Parts

 [www.argos-support.co.uk](http://www.argos-support.co.uk)

 [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk)

 0370 112 1928

## Customer Support

 0345 640 2020



# Safety and Care Advice

---


## Product Details

Clothes Hanger Stand 7144660

## IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- This product has been constructed to be used in the domestic environment only and not for commercial purposes.

- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.



- We do not recommend the use of power drill/drivers for inserting screws as this could damage the unit. Only use hand screwdrivers.
- Parts of the assembly will be easier with 2 people.
- Dispose of all packaging carefully and responsibly.

## Care and maintenance

---

- Only clean using a damp cloth and mild detergent. Do not use abrasive cleaners.
- Use a dry cloth to clean the product, furniture polish is not recommended.
- From time to time check that there are no loose screws, nuts or bolts. If there are please re-tighten.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

## Additional Guidance

---

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightened properly.
- Maximum loading weight 31kg

# Fittings (Shown to scale)

---




A

Long Screw x 16 (22mm)




B

Short Screw x 4 (16mm)




C

Nut x 4



D

Spanner x 1



E

Allen key x 1

# Hardware

---

1



Upper Side Frame x 2 (2553mm)

2



Lower Bending Tube x 2 (1933mm)

3




Lower Center Tube x 1 (776mm)

4




Upper Black Tube x 3 (776mm)

5




Wire Shelf x 2

# 1





 Repeat  
x2



# 2

- a. Use Allen Key E and Long Screw A to connect Lower Center Tube 3, Upper Black Tube 4, Wire Shelf 5 with Upper Side Frame 1 and Lower Bending Tube 2. (see fig. a)
- b. Use Short Screw B and Nut C to fasten Upper Side Frame 1 and Lower Bending Tube 2. (see fig. b)



# 3

