

Safety Instruction Manual

1. General Safety Disposal Instructions



WARNING: Fire and Injury Hazard

Strictly prohibit disposing of lit cigarettes, burning matches, or high-temperature hot ashes directly into the waste bin. Flammable and high-temperature combustible substances may ignite garbage in the bin, trigger fire hazards, and cause property damage or personal safety accidents.

2. Sharp Objects Disposal Requirement



WARNING: Cut Injury Hazard

All sharp objects must be fully wrapped with protective materials (such as waste paper, plastic foam, adhesive tape, etc.) before being placed into the bin. This operation effectively prevents sharp edges from piercing the waste bin, scratching cleaning personnel, and causing secondary injury risks during garbage collection and transportation.

3. Daily Maintenance & Cleaning Specification



NOTE: Sanitation & Service Life Maintenance

The waste bin shall be cleaned regularly to remove residual garbage, stains and peculiar smell. Regular cleaning can avoid bacterial growth, prevent bin corrosion and damage, maintain the hygiene of the use environment, and extend the service life of the waste bin.