


8 SEATER STORAGE BOX - SINGLE STOOL

Assembly Instructions - Please keep for future reference

7525337



Dimensions

Width - 37cm

Depth - 37cm

Height - 36cm



Important:

Do not fully tighten all screws until assembly is complete.

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

If you need help or have damaged or missing parts, call the Customer Helpline: 0345 640 0800

Retailer: Argos

Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW

Issue 2: 05/11/12



Safety and Care Advice

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

- Check you have all the components and tools listed on pages 2.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product during assembly, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the chair or your floor.

- Parts of the assembly will be easier with 2 people.

- This product is for domestic use.



- We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.

- Dispose of all packaging carefully and responsibly.

- Maximum safe seated weight: 110kgs.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- Make sure each stud matches the corresponding figure to ensure correct assembly.

- From time to time check that there are no loose nuts on this chair.


- Assemble all parts and nuts loosely during assembly, only once the product is complete should you fully tighten the nuts.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Components-Parts

If you have damaged or missing components, call the Customer Helpline: 03456 400 800


Please check you have all the parts listed below



1 Left panel x 1




2 Right panel x 1




3 Bottom panel x 1




4 Front panel x 1



5 Back panel x 1



6 Top panel x 1



7 Seat cushion x 1

Components-Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


A



M6x30

Screw x 12

B



M6x35

Screw x 2

C



Plastic washer x 2

Tools required



Allen Key x 1


Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1


Use screws **A** to fit left panel **1**, right panel **2** and bottom panel **3** together.



Important:
Do not fully tighten
nuts at this stage.

Step 2


Use screws **A** to fit front panel **4**, back panel **5** to the unit.



Assembly Instructions

Step 3

Use screws **B** plastic washer **C** to fit top panel to the unit.



Tighten all screws.




Important:

After all the parts are positioned, you can now fully tighten all screws fixed on previous steps.

Step 4

Put the cushion **7** on the stool.



Assembly is complete

If you need help or have damaged or missing parts, call the Customer Helpline: 0345 640 0800

Retailer: Argos

Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW