


ISLINGTON TV UNIT

Assembly Instruction - Please keep for future reference

804/7096



Dimensions

Width - 128cm
Depth - 40cm
Height - 52.5cm


Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline
Argos = 0345 6400800

Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.




Assembly Instructions

Step 1

Attaching felt pad

a: Remove the papers on felt pad **A** as shown.

b: Attach 4 felt pad **A** onto the bottom of all legs as shown.



If you need help or have damaged or missing parts, call the Customer Helpline
Argos = 0345 6400800

