



- Tips
- Conseils
- Consejos

Easy storing / Rangement facile / Fácil de guardar




- Hair extensions
- Extensions capillaires
- Extensiones de pelo



- Requires 2 AA batteries, Batteries not included.
- Alkaline batteries are recommended.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Do not mix new and old batteries.
- Remove batteries if not used for long period of time.
- Rechargeable batteries are only to be charged under adult supervision.
- Exhausted batteries should be removed and properly disposed.
- Non-rechargeable batteries are not to be recharged.
- Battery is to be inserted with the correct polarity (+ and -).
- The supply terminals are not to be short-circuited.
- Cleaning and maintenance procedures which are necessary for the safe operation of the toy.
- The packaging and instruction sheet have to be kept since they contain important information.
- Nécessite 2 piles LR6 (AA). Les piles ne sont pas fournies.
- L'utilisation de piles alcalines est recommandée.
- Ne jamais utiliser ensemble différents types de piles, telles que piles alcalines, standard (carbone-zinc) ou rechargeables (nickel-cadmium).
- Ne jamais utiliser ensemble des piles neuves et des piles usagées.
- En cas de non utilisation prolongée de l'objet, ôter les piles.
- Les accumulateurs doivent être chargés uniquement sous le contrôle d'un adulte.
- Les piles usagées doivent être ôté et jetées de façon appropriée.
- Ne jamais recharger des piles non rechargeables.
- Les piles doivent être insérées en respectant la polarité (+ et -).
- Les bornes d'alimentation ne doivent pas subir de courts-circuits.
- Il convient de respecter les procédures de nettoyage et d'entretien, nécessaires à une utilisation du jouet en toute sécurité.
- Veuillez conserver l'emballage et les instructions car ils contiennent des informations importantes.
- Se requieren 2 pilas de tipo AA. Las pilas no están incluidas.
- Se recomienda usar pilas alcalinas.
- No combine pilas alcalinas con pilas estándar (zinc-carbono) o pilas recargables (níquel-cadmio).
- No combine pilas nuevas con pilas usadas.
- Retire las pilas si no usa el aparato por tiempo prolongado.
- Recargar las pilas recargables solo bajo vigilancia adulta.
- Las pilas descargadas deben de retirarse del aparato y eliminarse de manera apropiada.
- Nunca intente recargar pilas no recargables.
- Las pilas y acumuladores deben ser colocados respetando la polaridad indicada (+ y -).
- Los terminales de alimentación no deben ser sometidos a cortocircuitos.
- Es importante observar los procedimientos de limpieza y mantenimiento para el uso seguro del juguete.
- Conserve el embalaje y las instrucciones, ya que contienen información importante.




WARNING:
CHOKING HAZARD - Small parts
Not for children under 3 years




1 - COVER

How to use the hair braider? /
Comment utiliser les tresseuse a cheveux? /
Cómo utilizar las tressador de cabello?



1. Open the battery case cover with screwdriver; install 2 "AA" (LR6) batteries, then close it.
2. Attach the end strands to the prongs by pressing and releasing the prongs.
3. Push the button upwards until each individual strand becomes thin.
4. Then press downwards to spin each thin braid together until the thick braid is done.
5. Hold and release the hair with care and tie the end using elastic band.

How to use the hair braider : /
Comment utiliser les confectionneur de meches perlees :
Cómo utilizar las aplicador de mostacillas para cabello :



2

3

4