


10X8CM

Twin Bell Alarm Clock User Guide



Battery Placement

Notice the +/- direction of the sign and put the batteries in the compartment on the clock's back.

To Set The Time

Turn the left setting knob anti-clockwise wise to the desired time.

To Set The Alarm

Turn the right setting knob anti-clockwise wise to the desired alarm time.

To Activate/Deactivate Alarm

To activate the alarm, shift ON/OFF button to the ON position.

To turn alarm off, shift ON/OFF button to the OFF position.