Singlebed - Brooklyn

IMPORTANT! KEEP FOR FUTURE REFERENCE

8529198



Dimensions

Length - 200,4cm Depth - 100,2cm Height - 84,4cm Weight - 26,6kg

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0045 7668 8055** or e-mail: order@flexa.dk

A Safety and Care Advice

Important – Please read these instructions fully before starting assembly

80-23101-65 Singlebed

IMPORTANT! KEEP FOR FUTURE REFERENCE

PLEASE DISPOSE OF PACKAGING MATERIAL. PLASTIC BAGS CAN BE DANGEROUS TO YOUNG CHILDREN

WARNNG! Not suitable for children under 4 years.

WARNING! Do not place this child's bed near heat sources, windows and other furniture. WARNING! Do not use this child's bed if any of the parts are broken, torn or missing. WARNING! Once assembled, this bed must not be disassembled. Screws must not be removed once inserted.

> This child's bed is to be used with a 1900mm x 900mm mattress. Suitable for over 4 years old to adults.

All assembly fixings should be checked periodically and re-tightened where necessary. Children are likely to play, bounce, jump and climb on beds, therefore the child's bed should not be placed too close to other furniture or windows, blind cords, curtain pulls or other strings or cords, and should be placed either tight to any wall or have a gap of 300mm between the wall and the side of the bed. Always place the side of the bed with the safety rail against a wall.

Any additional or replacement parts should only be obtained from the manufacturer or distributor. This product complies to standard BS8509: 2008+A1:2011

WARNING

YOUR CHILDREN'S SAFETY IS YOUR RESPONSIBILITY

CARE AND MAINTENANCE

To clean use a damp cloth, avoiding the use of strong detergents or abrasives.

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers **for inserting screws**, as this could

damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

Care and maintenance


• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners. • From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Parts

If you have damaged or missing components, call the **Customer Helpline: 0045 7668 8055**

Please check you have all the parts listed below




Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

No. 3913-06100	No. 3922-06014	No. 3902-40030
	B	€ (]
M6x100mm Connecting bolt x4	M6 ø10x14mm Barrel nut x4	4,0x30mm Chipboard screw x36
No. 3930-10050	No. 3930-08050	No. 3930-05040
10x50mm Dowel x18	8x50mm Dowel x4	5x40mm Dowel x2
No. 3901-40070	No. 3909-631051	
4,0x70mm Chipboard screw x8	6,3x105mm Assembly screw x8	

Tools required



Step 1

Insert the dowels **D** into the holes in bedsides **10** and endrail **8** and **7**. Insert Ø8 dowels **G** into the holes in endrail **7**.

It may be necessary to tap the dowels in very gently with a small hammer.

Step 2


Attach endrails 7 to top rails 6 using screws **6**.

Don't overtighten.

Step 3

Attach leg **2** to endrail **7** using the inserted dowel only.


Attach endrail ⁸ and filling ⁹ to leg ² using the inserted dowel only.



Step 4

Attach leg 1 to endrails 7 and 8.


Insert assembly screws and fasten with the allen key. Don't overtighten.



Step 5

Insert Ø5 dowel [•] into the leg ⁴. Attach leg ⁴ to endrail ⁷ using the inserted dowels only.

Attach endrails 8 and filling 9 to leg 4 using the inserted dowels only.




Step 6

Insert Ø5 dowel **D** into the leg **3** as in the previous step.

Attach endrail ⁸ to leg ⁴, at the same time should leg ³ be attached to the two endrails ⁸ and ⁷ using the inserted dowels only.


Insert assembly screws and fasten with the allen key. Don't overtighten.



Step 7

Attach bedside 10 to the bed by placing the dowels into the holes in legs 2 and 4.


Push 2 barrel nuts ^(B) into the small holes in bedside ⁽¹⁰⁾. Push 1 connecting bolt ^(A) through legs ⁽²⁾ and ⁽⁴⁾ to meet the barrel nuts ^(B) and fasten with the allen key.



Step 8

Attach the second bedside 10 to the bed by placing the dowels into the holes in legs 1 and 3 as in the previous step.

Push 2 barrel nuts ³ into the small holes in bedside ¹⁰. Push 1 connecting bolt ⁴ through legs ¹ and ³ to meet the barrel nuts ³ and fasten with the allen key.




Step 9

Place two slats **5** in the ends of the bed, against the legs. Fasten with four chipboard screws **6**.

Place one slat 5 in the bed. Follow the measurements.

Push the bedsides 10 together whilst attaching middle slat 5 to the bed with two chipboard screws **C**.




Step 10

Position the remaining fifteen slats 5 in the bed with an approximate distance of 52 mm between each.

Fasten each slat with two screws **G**

Assembly is complete.





If you need help or have damaged or missing parts, call the **Customer Helpline: 0045 7668 8055** E-mail: order@flexa.dk

Your 2 Year Guarantee

Peace Of Mind

Knowing Your Furniture Is Protected

Protection received within the Manufacturer's Guarantee	Optional Added Protection with Furniture Care	
Covers you for manufacturing defects for 2 years.	Covers you for accidental damage up to 3 years for incidents such as household spills, rips, tears and burns. Accidental damage cover begins from the moment your plan starts.	
In the event of a problem within this time please call 0345 640 0800 , or visit an Argos		
store. Please retain your receipt and order number as proof of purchase.	If you want to purchase Furniture Care visit https://argos.productaftercare.co.uk or go into an Argos store.	

Key exclusions applying to both the Manufacturer's Guarantee and Furniture Care include where the fault is due to misuse, abuse, deliberate damage, wear and tear, neglect, use in contravention with the instructions, or if the product has been the subject of unauthorised alterations or commercial use (for full list of exclusions please visit **https://argos.productaftercare.co.uk** or visit an Argos store for more information).

You have up to 45 days post purchase to take out Furniture Care.

Terms and conditions apply. Your statutory rights remain unaffected.

Register For Your Manufacturer's Guarantee

Thank you for choosing Argos Home. We hope you love your shiny new things!

To provide you with the best possible after sales service, don't forget to visit **https://argos.productaftercare.co.uk** where you can **register** for your guarantee.

Once you've registered, you can upload your receipt to store safely online, alongside details of our after sales support service, ready at hand should you need it.

You can also take out Furniture Care which protects you against accidental damage, from the moment you take the plan out, to keep your new furniture looking newer for longer.

Register Today

https://argos.productaftercare.co.uk