


70mm

85mm

## Instruction Manual:

### Flashing, Spinning;

Press B1 once: light be turned on  
(automatically extinguish after about 8 seconds.)  
Rotating the spin part for spinning.



### Display:

1. Normal time display: hour&minutes.
2. Press B2 once: month&date( automatically return to normal time display.)
3. Press B2 twice: seconds(press B2 again return to normal time display.)

### Setting the watch:

1. Month: press B3 twice to display month and set the month with B2
2. Date: press B3 to display the date and set the date with B2
3. Hour: press B3 to display the hour and press B2 to set the hour ("A" for AM and "P" for PM time.)
4. Minutes: press B3 to display the minutes and set the minutes with B2.
5. Press B3 once more to return to normal time display and then press B2 once to time working.
6. Battery: 2×LR41

**DO NOT MIX OLD AND NEW BATTERIES**

**DO NOT MIX ALKALINE, STANDARD,  
OR RECHARGEABLE BATTERIES.**

**DO NOT IMMERSE IN WATER**

**DO NOT WEAR IF CASEBACK IS MISSING OR DISASSEMBLED**

**MADE IN CHINA**