



















reebokfitness.com










ZJET 460 TREADMILL ASSEMBLY GUIDE




 A	 B	 C	 B04	 B05
 C09	 C14	 C15	 D07	 D12
 D23	 D35	 E06	 E26	









No.	Part description	Qty	No.	Part description	Qty
A01	Base frame	1	D18	Bolt M6*25	6
A02	Main frame	1	D19	Screw ST4.2*20	3
A03	Incline bracket	1	D20	Screw ST4.2*12	12
A04	Console bracket	1	D21	Bolt M5*30	4
A05	Motor bracket	1	D22	Bolt M5*16	4
A06	Left upright tube	1	D23	Bolt M5*12	8
A07	Right upright tube	1	D24	Bolt M5*8	15
A08	Fan bracket	1	D25	Screw ST4.2*30	7
B01	Front roller	1	D26	Screw ST4.2*20	2
B02	Back roller	1	D27	Screw ST4.2*12	4
B03	Cylinder	1	D28	Screw ST4.2*12	43
B04	Cross wrench with screw driver	1	D29	Screw ST2.9*16	3
B05	5# Allen wrench	1	D30	Screw ST2.9*8	20
B06	Transport wheel bushing	4	D31	Screw ST2.9*6	18
B07	Speaker net	1	D32	Screw ST3.5*10	8
B08	Pulse steel plate	4	D33	Screw ST2.9*8	4
B09	Safety key steel plate	1	D34	Washer 6	3
B10	Locking pin	1	D35	Washer 8	18
B11	Bushing	4	D36	Flat washer 8	13
B12	Side rail pressing sheet	6	D37	Washer 10	2
C01	Console top cover	1	D38	Spring washer 8	6
C02	Console bottom cover	1	D39	Flat washer φ5*φ13*1.0	4
C03	Console panel	1	D40	Big washer φ10*φ26*2.0	8
C04	Plastic holder	1	E01	AC single wire 200mm blue	1
C05	Left handle bar top cover	1	E02	AC single wire 200mm brown	1
C06	Right handle bar top cover	1	E03	AC single wire 350mm blue	1
C07	Left handle bar bottom cover	1	E04	AC single wire 350mm brown	2
C08	Right handle bar bottom cover	1	E05	Grounding wire 350mm	1
C09	Safety key	1	E06	Power wire	1
C10	Handle bar decoration ring	2	E07	Power socket	1
C11	Rubber pad	1	E08	On-off button	1
C12	Handle bar	2	E09	Overload protector	1
C13	Motor top cover	1	E10	Safety key sensor	1
C14	Left upright tube cover	1	E11	Running board	1
C15	Right upright tube cover	1	E12	Magnet core	3
C16	Back end cover	1	E13	Magnet ring	1
C17	Running belt	1	E14	Incline motor	1
C18	Motor bottom cover	1	E15	DC motor	1
C19	Black cushion	4	E16	Console	1
C20	Blue cushion	2	E17	Control board	1
C21	Plastic pad	4	E18	Button board	1
C22	Motor belt	1	E19	Top signal wire	1
C23	Transport wheel	2	E20	Bottom signal wire	1
C24	Adjustable wheel	2	E21	Speed quick button board	1
C25	Ring-shape wire plug	2	E22	Incline quick button board	1
C26	Flat foot pad	4	E23	Hand pulse top signal wire	1
C27	Cone-shape cushion	1	E24	Hand pulse bottom signal wire	2
C28	Air cushion	2	E25	Speaker	2
C29	Air cushion base	2	E26	Mp3 wire	1
C30	Left side rail	1	E27	Audio input and output board	1
C31	Right side rail	1	E28	Amplifier board input wire	1
C32	Fan top cover	1	E29	Audio input and output wire	1
C33	Fan bottom cover	1	E30	USB power wire	1
C34	Fan fixed base	1	E31	USB board	1
D01	Nut M6	2	E32	Speed sensor	1
D02	Nut M8	11	E33	Fan top wire	1
D03	Nut M10	6	E34	Fan middle wire	1
D04	Bolt M10*90	1	E35	Fan bottom wire	1
D05	Bolt M10*45	1	E36	Fan	1
D06	Bolt M10*30	4	F01	Hide board	2
D07	Bolt M8*50	6	F02	Screw ST4.2*12	6
D08	Bolt M8*40	2	G01	Belt hook	2
D09	Bolt M8*45	1	G02	Screw ST4.2*12	4
D10	Bolt M8*30	1	H01	Filter	1
D11	Bolt M8*20	4	H02	Inductance	1
D12	Bolt M8*15	12	H03	AC single wire	1
D13	Bolt M8*35	6	H04	Grounding wire	1
D14	Bolt M8*40	1	H05	Screw ST4.2*12	5
D15	Bolt M8*35	1	K01	Side rail anti-slip pad	2
D16	Bolt M6*55	3	K02	Side rail anti-slip sticker	2
D17	Bolt M6*40	2	K03	Screw ST4.2*12	4

