

How to use your G-spot vibrator

Unscrew the base and insert 1 x AA battery as indicated. Do not remove the paper sleeve. Screw the base back on.

Press the button on the base to begin vibrations, then press repeatedly to move through the 3 speeds and 7 patterns. Press and hold the button to turn the toy off.

Use with water-based lubricant to enjoy your toy at its best.

Clean after use with sex toy cleaner and leave to air dry until next time.

If you're not going to use your toy for a few days, remove the batteries.

Warning: To avoid injury or aggravation of pre-existing conditions, do not use on swollen or inflamed areas or skin lacerations. No medical claims are warranted or implied by use of this product.

www.lovehoney.co.uk