


# Double Tidy Rail

Assembly Instructions—Please keep for future reference

8751698



## Dimensions

Width - 89.5cm

Depth - 38.5cm

Height - 101/167.5cm

**Important - Please read these instructions fully before starting assembly**

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800



## Safety and care advice

Important –Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Assemble the unit as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.
- If using power tools, please follow the safety instructions supplied with the tools.



- We do not recommend the use of power drill/ drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.


## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Note: if required the next page can be cut out and used as a reference throughout the assembly. Keep this page with these instructions for future reference.

# Components – Parts

Please check you have all the panels listed below




1 Rail x 2 (89cm)




2 Bottom Support x 2 (83cm)



3 Bottom Tube x 4 (87cm)




4 Upper Tube x 4 (78cm) (Inserted inside component 3)



5 Foot x 2 (39cm)



6 Castor x 4



7 Lock x 2 (33cm)



Components - Fittings


If you have damaged or missing components,  
call the **Customer Helpline: 08456 400800**

Please check you have all the fittings listed below


**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<div><div>A</div><div>Connector x 4</div><div></div></div>		
---	--	--

Tools required



Ruler - Use this ruler to help correctly identify the screws



# Assembly Instructions


## Step 1

### Fitting the Feet

NOTE: It would be useful to ask someone to help you at this stage.


a: Insert Bottom Supports 2 into Feet 5.

a:



b: Insert Bottom Tubes 3 into Feet 5.

b:



# Assembly Instructions

## Step 2

### Fitting the Rails


NOTE: It would be useful to ask someone to help you at this stage.

a: Insert Rail **1** into Connectors **A**.

b: Insert Upper Tubes **4** into Connectors **A**.

Repeat steps a and b to assemble the other Rail **1**.

c: Insert Castors **6** into Feet **5**.



# Assembly Instructions

## Step 3

### Finishing the Unit

NOTE: It would be useful to ask someone to help you at this stage.

a: Insert Locks **7** onto the Top of Bottom Tubes **3**. Align the Screw on Lock **7** into the hole on Bottom Tube **3**.





b: Insert Upper Tubes **4** into the Locks **7**.

Set the height of the unit using the Upper Tubes **4**. Ensuring the Locks **7** are loosened, slide the tubes to the desired height and tighten the Locks to fix in position.

Adjustment Range: 101-167.5cm.

c: With help, place the unit in the intended position.

The assembly is now complete.



If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800