





## G-SHOCK AE-1200WHD-1AVEF

### Specifications

- ⇒ 100M WR
- ⇒ Daily Alarm
- ⇒ Stopwatch
- ⇒ World Time
- ⇒ LED Light
- ⇒ 10- Year Battery



Model variations may differ in appearance from the example above.

<b>World Time</b>	Displays the current time in major cities and specific areas. Current time in 48 cities (31 time zones)	Press button <b>C</b> to enter World Time mode, your current world time city code should appear on the digital display for two seconds. Press <b>D</b> to get the next city code in order.   <p>City code</p> <p>Current time and date in the zone of the selected city code</p>
<b>Stop Watch</b>	Elapsed time, split time and two finishes	Press button <b>C</b> until display shows stopwatch function (STW) Start and stop the stop watch using button. Measure times:   <p><b>Elapsed Time</b></p> <p>Start → Stop → Re-start → Stop → Clear</p> <p><b>Split Time</b></p> <p>Start → Split → Split release → Stop → Clear</p> <p><b>Two Finishes</b></p> <p>Start → Split → Stop → Split release → Clear</p> <p>• The split time screen alternates between a split indicator (SPL) and the split time at two-second intervals.</p>
<b>Daily Alarms</b>	To Set an Alarm <b>Press D:</b>   <p>Alarm on indicator</p> <p>Alarm number</p> <p>Alarm time (Hour - Minutes)</p> <p>Your watch has a total of five alarms, each of which you can configure as a daily alarm or one-time alarm.</p> <ul style="list-style-type: none"> <li>• Daily Alarm: Sounds at the preset time each day.</li> <li>• One-time Alarm: Sounds once at the preset time and then is disabled automatically.</li> </ul> <p>You can also turn on an Hourly Time Signal that causes the watch to beep twice every hour on the hour.</p> <ul style="list-style-type: none"> <li>• All of the operations in this section are performed in the Alarm Mode, which you enter by pressing <b>C</b> (page E-5).</li> <li>• Alarms operate in coordination with the current Home City Time.</li> </ul>	In Alarm mode use Button <b>D</b> to scroll through alarm screens you want to set is displayed. After selecting the alarm Hold down Button <b>A</b> for two seconds until hour digits start to flash, this is the setting mode. Press <b>C</b> to move flashing between the hour and minute settings. While a setting is flashing, use Button <b>D</b> (+) and <b>B</b> (-) to change it. Press <b>A</b> to exit the setting mode. To turn alarm on and off, Press <b>D</b> to select an alarm, then Press <b>A</b> to toggle it on and off.  
<b>Water Resistant</b>	Suitable for bathing, swimming, and showering. not for diving.	
<b>LED Light</b>	Includes an After-Glow feature that keeps the illuminator turned on for a few seconds after the light button released.	In any mode (except when setting screen is on the display) <b>Press B</b> to illuminate display
<b>10 Year Battery</b>	Battery power lasts up to approximately ten-years without changing.	CASIO's advanced technology allows extended battery life for up to ten-years . All timekeeping modes and functions of the watch can be used continuously for up to seven-years without a battery change.