

148X210mm




General safety	
Do not leave child u This product is a toy This toy is not inten	embled parts/sections unattended due to potential hazards! Inattended when playing with this product. 7. Do not allow child to sit on this product. ded for teaching the baby how to walk. To prevent injury from falls, the c oden walker until your child walk independently.
Warning	
	ut of the reach of children under 36 months because of possible choking e performed by an adult.
Parts	If you need help or have damaged or missing parts, call the Customer Helpline: 03456 400 800.
Please check vo	u have all the parts and fittings listed below
rolley :	
Handle x1	Cylinder x 2
~	O B Metal washer x2



Step 2:

Put the metal washer on the screw, then insert the screw to the hole at the bottom and fix it as shown.

Important: Ensure all parts are fully assembled before giving to the children.



Care and Maintenance

- Periodically check all fittings to ensure that none have come loose.
- Any loose fittings must be tightened using the correct tool.

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400 800.** Produced for Chad Valley Toys. *Country of origin:* CHINA. *Address:* 489-499 Avebury Boulevard, Central Million Keyness,MK9 2NW.

4

3

CE