Drio Sideboard


Assembly Instructions - Please keep for future reference

DRIO-SB-SS17-A

Dimensions

Width-180cm Depth -45cm Height - 75cm

Tools required



Important - Please read these instructions before assembly

If you need help or have damaged or missing parts, email: customerservices@habitat.co.uk or call: 0344 499 4686





Safety and Care Advice

Important - Please read these instructions fully before starting assembly

Check you have all the components and tools listed on the front cover and pages 3 - 4.

Remove all fittings from the plastic bags and separate them into their groups.

Keep children and animals away from the work area, small parts could choke if swallowed.

Make sure you have enough space to layout the parts before starting.

cause damage.

Assemble the item as close to its fi nal position (in the same room)as possible.

Do not place furniture directly in front of radiators, fi res or any other source of heat.



Parts of the assembly will be easier with 2 people.

Do not stand or put weight on the product, this could Assemble on a soft level surface to avoid damaging the unit or your floor.



We do not recommend the use of power drill/drivers for inserting screws, as this could

damage the unit. Only use hand screwdrivers.

Dispose of all packaging carefully and responsibly.

Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

From time to time check that there are no loose screws on this unit.

This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Cleaning and care of wood and wood veneer

Maximum weight limit

for each shelf is shown below.

Important: Recommended maximum load

Cleaning and care of wood and wood veneer.

Clean marks with a damp cloth. Do not allow spillages to stay on the surface for long. To remove stubborn stains, wipe over with a damp cloth and washing up liquid.


Do not use abrasive cleaners.

Do not clean with products contaiing the following: Acetone,

(e.g nail varnish remover). Ammonia (e.g.bleach). or Sodium hydroxide (e.g. Caustic soda, drain and oven cleaners).

In the event of accidental contact with aggresive cleaners, rinse thoroughly with water.

Use place mats and coasters to protect the surface from moisture and heat.



General information

If for any reason you should have problems with your Habitat product, please contact the store from which you purchased it.

Please retain your receipt as proof of purchase.

If you have any comments or suggestions regarding this product, assembly instructions or service


received, please contact the store or Habitat Head Offi ce via its web site: www.habitat.co.uk or write directly to: Habitat Retail Ltd. 489-499 Avebury Boulevard, Milton Keynes MK9 2NW

Components - Panels


If you need help or have damaged or missing parts, email: customerservices@habitat.co.uk or call: 0344 499 4686

Please check you have all the panels listed below

BC Note: There are 'Batch Code' lables where shown on the indicated items, these should be retained.



Components B and fittings pack supplied inside drawer




Components - Fittings


Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fi ttings may be supplied than are required.


Ruler - To help correctly identify the fixings		
Fittings 0 10 20 30 40 50 60 70 80 90 100 110 120		
Wooden dowels x 2	Screws x 2	Connector x 2
		A6 Dame
Screws x 4	Felt x 4	Screws x 4
	69	
Connector x 2	Hex key x 1	
	·	

Step 1










Step 4



Step 5

Warning : This Piece of Furniture Must Be Attached To The Wall Using The Wall Brackets Provided

In order to prevent overturning this sideboard must be attached to an adjacent wall with the metal wall brackets provided.


Serious or fatal crushing injuries can occur from furniture tipping over. To help prevent topple over :-

- Use the wall brackets provided
- Never allow children to climb or hang on furniture
- Unless specifically designed to accommodate, do not set TV's or other heavy objects on top of this product.


Due to the different types of wall you might have in your home Habitat cannot provide you with the exact fixings for your wall. We supply you with the fixings for attaching the brackets to the furniture. You must assess the type of wall you want to fix the furniture to and provide the appropriate type of wall fixings. If you are in any doubt about which type of wall fixings to use please seek professional help or ask your local hardware store.

Always ensure that wall to be drilled into is free from hidden electrical wires, water and gas pipes.

For more information about wall fixings please refer to the Wall Mounting and Fixings Guide at the back of this instruction.




Attaching brackets to wall - please remember you must source and supply the fixings for attaching to your particular type of wall including the wall screws and wall plugs.



Step 7

If necessary door position and line can be adjusted by adjusting the hinges.

C



A Guide to - Wall Mounting & Fixings

Important note:

Wall Fixings:



 because of the variety of different wall types, Habitat cannot provide you with the exact fixings you will need to fix this product to the wall.

You must first identify the type of wall you intend to fix product onto and then contact your local hardware store to get the appropriate fixings.




Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:


- 1: General rule: Always use a larger screw and wall plug if you are not sure.
- Ensure you use the recommended drill bit to match the wall plug and hole size.
- Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls



Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.




You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.3 "Cavity Fixing" wall plug



For use with plasterboard partitions or hollow wooden doors.


No.4 "Cavity Fixing-Heavy Duty" wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.


Safety: Always check the fitting and location to ensure your safety in and around the home.

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.