



Pair New Device "off Mode"
Mode Coupé
Vincular Nuevo Dispositivo "modo Apagado"
Accoppiamento Nuovo Dispositivo "modalità Spento"
Emparellar Novo Dispositivo "modo Desligado"
Mit Neuem Gerät Kopplein "ausgeschalteteZustand"
New Apparait Paren "lutmodus"
Pardun Ny Enhet "skjutet Tillstånd"
Modosta Uusi Laitteen "off-tila"
Sammenkoble Ny Enhet "av-modus"
Para Ny Enhet "av-läge"
Сопрежение Новое Устройство "выключенноеРежиме"
配对新设备 "关机模式"
新しいデバイスとペアリング "オフモード"
"שי" קיבולת חזקה "חי" קיבולת עדי

Pairing Mode
Coupler Nouvel Appareil "mode Off"
Vincular Nuevo Dispositivo "modo Apagado"
Accoppiamento Nuovo Dispositivo "modalità Spento"
Emparellar Novo Dispositivo "modo Desligado"
Mit Neuem Gerät Kopplein "ausgeschalteteZustand"
New Apparait Paren "lutmodus"
Pardun Ny Enhet "skjutet Tillstånd"
Modosta Uusi Laitteen "off-tila"
Sammenkoble Ny Enhet "av-modus"
Para Ny Enhet "av-läge"
Сопрежение Новое Устройство "выключенноеРежиме"
配对新设备 "关机模式"
新しいデバイスとペアリング "オフモード"
"שי" קיבולת חזקה "חי" קיבולת עדי

Power - On
On
Encendido
Accensione
Ligar
Ein
Aus
Utzetting
Skru Op For Strøm
Virta Päälle/Av
Ström Av
Ström Av
På
Uvklippen
Кнопка Включения
开机
電源 On
전원 켜기
تشغيل

Power - Off
Off
Apagado
Spengimento
Ligår
Ein
Aus
Utzetting
Skru Ned For Strøm
Virta Päälle/Av
Ström Av
Ström Av
På
Uvklippen
Кнопка Выключения
关机
電源 Off
전원 끄기
إيقاف التشغيل

Play/pause
Lecture/pause
Reproducir/pausa
Riproduzione/pausa
Reproducir/colocar Em Pausa
Wiedergabe/pause
Alpspeker/pauseren
Skru Op For Lydstyrken
Virta Päälle/Av
Ström Av
Ström Av
På
Uvklippen
Кнопка Воспроизведения/пауза
播放/暂停
電源/一時停止
재정지/일시 중지
تشغيل/إيقاف التشغيل

Volume Up
Volume +
Subir Volumen
Aumentar Volume
Diminuir O Volume
Wiedergabe/Leisten
Volume Omhoog
Skru Ned For Lydstyrken
Virta Päälle/Av
Ström Av
Ström Av
På
Uvklippen
Кнопка Увеличения Громкости
音量增大
音量を上げる
音量を下げる
音量减小
音量调高
音量调低
حجم الصوت أعلى
حجم الصوت أدنى

Volume Down
Volume -
Bajar Volumen
Riduzione Volume
Diminuir O Volume
Wiedergabe/Leisten
Volume Omhoog
Skru Ned For Lydstyrken
Virta Päälle/Av
Ström Av
Ström Av
På
Uvklippen
Кнопка Уменьшения Громкости
音量减小
音量を下げる
音量调高
音量调低
حجم الصوت أعلى
حجم الصوت أدنى

Track Forward
Piste Suurinta
Adlantar
Bravo Precedente
Faisa Anterior
Nächster Titel
Vorig Nummer
Skift Til Næste Musiknummer
Kelaus Etterpäin
Neste Spor
Nästa Ljudspår
Переходение На 1 Трек Вперед
下一曲目
次のトラックを再生する
다음 트랙으로
مسار التالي

Track Back
Ritroceder
Responder/colgar
Bravo Precedente
Faisa Anterior
Nächster Titel
Vorig Nummer
Skift Til Næste Musiknummer
Kelaus Etterpäin
Neste Spor
Nästa Ljudspår
Переходение На 1 Трек Назад
上一曲目
前のトラックを再生する
이전 트랙으로
مسار السابق

Answer/End
Ansvernd
Ritroceder/colgar
Responder/colgar
Bravo Precedente
Faisa Anterior
Nächster Titel
Vorig Nummer
Skift Til Næste Musiknummer
Kelaus Etterpäin
Neste Spor
Nästa Ljudspår
Переходение На 1 Трек Назад
上一曲目
前のトラックを再生する
이전 트랙으로
مسار السابق

Activate Assistant
Activer l'assistant vocal
Activer el asistente de voz
Attiver assistente vocale
Sprachassistenten aktivieren
Stemhulp activeren
Aktivér talestøtte
Vastaus/Apuääni
Aktiver talerassistent
Aktivera röstassistent
Активировать голосовую помощник
激活语音助理
ボイスアシスタントをアクティベートする
음성인기자 호출
حضور باصوت

Charge
Charge
Cargar
Carica
Cargar
Aufladen
Opåden
Ladning
Ladda
Zaryadka
충전
충전

Questions Visit: www.skullcandy.com
Si vous avez des questions: www.skullcandy.com
Si tienes dudas, visita: www.skullcandy.com
Domane Vistate il sito: www.skullcandy.com
Fazer perguntas: www.skullcandy.com
Fragen Besuch: www.skullcandy.com
Voor vragen bezoek: www.skullcandy.com
For sporssmål se: www.skullcandy.com
Vastauksia löytyy: www.skullcandy.com
For spørsmål, besök: www.skullcandy.com
Vid frågor, besök: www.skullcandy.com
Если у вас возникли вопросы, посетите: www.skullcandy.com
如有问题请访问: www.skullcandy.com
質問がある場合はこちらをご覧ください: www.skullcandy.com
질문 방문: www.skullcandy.com
www.skullcandy.com: پاکستان کی سب سے بڑی آن لائن ریٹیلر

For best quality avoid storing product in conditions above 100 degrees.
Pour assurer la meilleure qualité, évitez de garder aux températures qui dépassent 37,7 °C degrés.
Evite guardar el producto en temperaturas por encima de los 37,7 grados para asegurar su máxima calidad.
Para avere la migliore qualità evitare di conservare il prodotto in condizioni che superano i 37,7 gradi.
Para obter a melhor qualidade, evite guardar o produto em condições superiores a 37,7 graus.
Um die bestmögliche Qualität zu gewährleisten, Produkt nicht über 37,7 °C lagern.
Om de kwaliteit van dit product optimaal te houden, mag het niet bij temperaturen boven 37,7 °C worden opgeslagen.
For optimal kvalitet, undgå at opbevare produktet i temperaturer over 37,7 grader.
For optimal kvalitet ber du unnå å oppbevare produktet i temperaturer over 37,7 grader.
Für das beste Qualitätsniveau vermeiden Sie das Lagern des Produkts bei Temperaturen über 37,7 Grad Celsius.
Для наилучшего качества избегайте хранения продукта в условиях выше 37,7 градусов.
为了获得最佳品质，避免将产品置于高于37.7摄氏度的环境中。
最高の品質を保持するため、37.7°C以上の条件で製品を保管しないでください。
最高の品質を維持するために、37.7°C以下の条件で製品を保管してください。
최고의 품질을 위해 제품을 37.7°C 이하의 조건에서 보관하십시오.
حفظ المنتج في درجة حرارة أقل من 37.7 °C للحصول على أفضل جودة.

Americas
Skullcandy, Inc.
6301 N Landmark Dr.
Park City, UT 84098, USA
Skullcandy.com
Canada
Skullcandy Canada ULC
329 Railway St. Unit 205,
Vancouver, BC, V6A 1A4
Canada
Skullcandy.ca
Europe
Skullcandy Europe BV
Postbus 425
5500AK Velthoven
Nederland
Skullcandy.eu
Mexico
Skullcandy Mexico S de RL de CV
Aristoteles 218
Polanco IV Sección, Miguel Hidalgo
11550, Mexico City, Mexico
Skullcandy.mx
Japan
Skullcandy Japan 合同会社
〒150-0001 東京都渋谷区神宮前
5-17-11 パークサイドオーサケビル
Skullcandy Japan アスチマーサービズ
施設についてのお問い合わせはこちら
Skullcandy.jp



English text for the back of the manual, including sections for pairing, power, play/pause, volume, track, and answer/end.

Spanish text for the back of the manual, including sections for pairing, power, play/pause, volume, track, and answer/end.

French text for the back of the manual, including sections for pairing, power, play/pause, volume, track, and answer/end.

German text for the back of the manual, including sections for pairing, power, play/pause, volume, track, and answer/end.

Italian text for the back of the manual, including sections for pairing, power, play/pause, volume, track, and answer/end.

Portuguese text for the back of the manual, including sections for pairing, power, play/pause, volume, track, and answer/end.

Chinese text for the back of the manual, including sections for pairing, power, play/pause, volume, track, and answer/end.

Japanese text for the back of the manual, including sections for pairing, power, play/pause, volume, track, and answer/end.

Additional Chinese text for the back of the manual, including sections for pairing, power, play/pause, volume, track, and answer/end.

Additional Japanese text for the back of the manual, including sections for pairing, power, play/pause, volume, track, and answer/end.

