

juice MAX 20,000mAh Portable Powerbank

Juice® has built the Juice®MAX power bank with you in mind. Speed is important when charging and when on the go, the Juice®MAX will charge your device at a speedy 2.4A and will allow around 7 full charges of an average mobile. This handy charger will also charge **TWO** devices at the same time, ready for when you need it most.

- Micro USB and USB C Input ports
- USB A Charging port - Output (2.1A) x2
- USB C Charging port - Output (2.4A)

Contents

Juice®MAX power bank, Micro USB to USB cable (for charging), User Manual and Juice carry bag

Overview



How to charge the Juice®MAX power bank

Ensure to fully charge the Juice®MAX power bank before first use, the LED will display 4 solid lights. Do this by charging and draining the power bank 3 to 4 times, this will ensure the Juice®MAX is fully optimised. To charge the Juice®MAX simply connect the supplied Micro USB cable into the power bank and the other end into your computer or to a mains plug (plug not supplied). The LED will flash when charging, when all 4 LEDs are lit, the bank is fully charged.

Lets get techy

Input	Micro USB - DC5V/2A USB-C - DC5V/2A
Output	Output USB A: DC5V/3A Output USB C: DC5V/3A Max Output at any time: 3A
Dimensions	139 x 67 x 24 mm
Net Weight	360g
Capacity	20,000 mAh / 74Wh (Lithium polymer battery cell)

Charging your gadgets

Always check the voltage your device can accept before charging with any Juice product, this will ensure full compatibility

1. Connect your device via the cable to the USB A or USB C port. You are able to charge from both output ports at the same time but the speed of charge will decrease for optimum safety. For other devices and Apple devices you will need to use your original cable that was supplied with your device, this will ensure compatibility.
2. Press the power button to turn the Juice®MAX on, now you can charge. Your device will show you when it is being charged via a sound or on the screen. The number of lit LEDs will decrease to show that power is being transferred from the power bank to your device.
3. When your device is fully charged or you want to stop charging, disconnect the cable.
4. In order to charge your device(s), you will need a cable compatible with your device. These come included as standard when purchasing most devices. Plug the device's standard USB A end in to the Juice®MAX, then plug the other end of the cable into the device you wish to charge.
5. Once charged, simply unplug your device and store your Juice®MAX power bank until you are ready to use it again, ensure to charge the power bank fully every 3 months to ensure it is kept in optimum condition.