


MAX

UK Bed Oak

UK 150 BED: 207X155.5X102CM

UK 135 BED: 199X140.5X102CM






Important-Please read these instructions before assembly

If you need help or have damaged or missing parts, email:
customerservices@habitat.co.uk or call 0344 499 4686

habitat 

Components




A x8



B x8




C x2



D x2



E x8



F x8



I x10




J x1



K x1






L x3



M x4



Retain batch code label.



Assembly Instructions

Please keep safe for future reference

Before assembling the furniture please identify all component parts.


It would be sensible to assemble the furniture as close to its final position as possible.

Do not place furniture directly in front of radiators, fires or any source of heat.

Ensure the surface on which you are assembling the furniture is flat and clear of anything that might scratch it.

Check all packaging carefully for components and fittings before discarding it.

1




5



C x2

2




4

5





L x1

3



1

2







D x2








M x4


4





5




6



7




8



 **Note:**
Adjust the height of the support leg to be off the floor when the bed is unoccupied - it should only touch the floor when the bed is occupied.
If the support leg is adjusted to be in constant contact with the floor you could drag and damage it when moving the bed.

-  **I x2**
-  **L x2**



 **DUO Slats supplied in separate pack.**

General Cleaning and Care Instructions

Dust regularly with a clean dry cloth.

Wipe up any spills immediately with a damp cloth and then dry the surface with a clean dry duster.

Repeat this procedure for periodic cleaning.

The use of furniture polish or spray is not necessary or recommended.

Light marks can be sanded away with very fine grade sandpaper and then the whole surface re-oiled.

Always use place mats and coasters to protect the surface from moisture and heat.

Reapply oil every year.

Apply a generous coating of Becker Acroma GA932 oil. Allow to absorb for 1-2 hours and wipe dry.

Follow directions given.