

# Aspley - 4FT Bed


Assembly Instructions - Please keep for future reference

481/9651

483/1938

553/3077

937/3233



## Dimensions

Width - 132cm

Depth - 202.5cm

Height - 102cm

**Important** –Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400 800**



# Safety and Care Advice

**Important** –Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.

• This product has been produced from natural timber; you may notice some variation in the grain and colour of different component parts which is normal for furniture produced using natural wood and is not the result of any manufacturing fault.

• The product has been treated with a wax and oil finish to prevent dirt ingress and preserve moisture.

• On unpacking the furniture you may notice an odour due to this treatment; this will disappear once the furniture is unpacked and assembled after a period of time.

• This process may leave some staining on the packaging material; please take care to ensure this does not transfer to clothing or carpeted surfaces during assembly.



as this could damage the unit. Only use hand screwdrivers.

• We do not recommend the use of power drill/drivers **for inserting screws**,

• Parts of the assembly will be easier with 2 people.

• Dispose of all packaging carefully and responsibly.

## Care and maintenance

- Use an appropriate furniture polish for natural wood furniture and a dry cloth to clean the product.
- Avoid placing the furniture in direct sunlight as this will cause the timber to prematurely age.


• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.


**Note:** If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

# Components - Panels

Please check you have all the panels listed below



**1** Headboard (100.0 x 129.9cm)



**2** Footboard (34.0 x 129.9cm)




**3** Side rail x 2 (190.0 x 11.0cm)



**4** Central rail (193.2 x 6.5cm)



**5** Slats x 24 (61.0 x 7.0cm)



**6** Middle support x 02 (22.5 x 7.0cm)



**7** Headboard top rail (132.0 x 6.8cm)



**8** Footboard top rail (132.0 x 6.8cm)


















# Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 03456 400 800**


Please check you have all the fittings listed below

## Note:


The quantities below are the correct amount to complete the assembly.  
In some cases more fittings may be supplied than are required.

<b>A</b>  Wooden dowel x 10 10 x 50mm 10005	<b>B</b>  3.5 x 16mm Screw x 8 9002	<b>C</b>  4.5 x 60mm Screw x 4 9019
<b>D</b>  4 x 35mm Screw x 48 9013	<b>E</b>  Headless bolt 1/4 x 70mm x 4 9301	<b>F</b>  1/4 x 110mm Bolt x 4 Cab. 17 9207
<b>G</b>  Half moon nut 1/4 x 4 6000	<b>H</b>  Nut 1/4 x 4 6100	<b>J</b>  Metal bracket x 2 3003
<b>K</b>  Washer x 4 Cod. 330103 6100	<b>L</b>  Spanner	<b>M</b>  Allen key x 1
<b>N</b>  82mm Spacer x 2 11507	<b>O</b>  7 x 90mm Bolt x 4 Cab. 13 9115	<b>P</b>  Metal dowel x 4 4002
<b>Q</b>  Locking nut x 4 4102	<b>R</b>  100mm Spacer x 2 11509	


## Tools required



Phillips screwdriver  
(medium & large)



Ruler/tape  
measure



Small  
hammer



Eye protection  
(when using a  
hammer or glue)


## Ruler - Use this ruler to help correctly identify the screws



# Assembly Instructions


## Step1

Insert dowels **A** into the side rails **3**.



## Step2

Insert wooden dowels **A** into headboard **1** and footboard **2** as shown.



# Assembly Instructions

## Step3


Fixing top rail



**Caution:**

Carefully lay the headboard top rail on a soft and clean surface to avoid damaging the product.

Fix headboard top rail **7** to the headboard **1** using bolts **O** and allen key **M**.



## Step4

Fixing top rails




**Caution:**

Carefully lay the footboard top rail on a soft and clean surface to avoid damaging the product.

Screw metal dowels **P** into footboard top rail **8**.

**Do not over tighten.**




# Assembly Instructions

## Step 5

Fit footboard top rail **8** to the footboard **2**.

Insert locking nuts **Q** where shown.


Use a screwdriver to turn locking nuts **Q** clockwise to lock.



## Step 6

Screw headless bolts **E** into footboard **2**.

**MAKE SURE TO SCREW THE HEADLESS BOLT ALL THE WAY**




# Assembly Instructions

## Step7

### Fixing metal brackets.


Fix metal brackets **J** into the pre drilled holes in the headboard **1** and footboard **2** using screws **B**.



## Step8

### Assembling central rail and inserting dowels.

Attach central rail **4** into the pre drilled holes in the middle supports **6** using screw **C**.





# Assembly Instructions

## Step 9

### Assembling side rails.




#### Important:

Two people are required for an easier assembly.

With help, fit one side **3** to the headboard **1**. Insert half moon nuts **G** as shown, then fix parts using bolts **F** and allen key **M**.

Repeat step 9 for the other side rail.




## Step 10

a: Insert washer **K** into the side rails. Fit the headless bolts in the footboard through the washers.

b: Fix headless bolts **E** using nuts **H** and spanner **L**.




Assembling of Step 9 and Step 10 will be easier with **2** people. It can also avoid damages or breaks of any part or component.



# Assembly Instructions

## Step 11

Attach central rail **4** to the metal brackets in the headboard and footboard using screws **B**.



# Assembly Instructions

## Step 12


### Assembling slats

Please fix the first slats **5** at the end of the rail and work towards the middle of the bed using the spacer **N** and **R** as shown to ensure correct spacing.

Note that for first slats, spacer **R** should be used in the middle and spacer **N** at the sides as shown in the drawing.

Fix slats in one side first, then fix them in the central rail by pushing the rail against the slats if necessary. Repeat in the other side rail.

Use screws **D** for fixing.



**Assembly is complete.**

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400 800**

# Your 2 Year Guarantee

## Peace Of Mind

### Knowing Your Furniture Is Protected

Protection received within the Manufacturer's Guarantee	Optional Added Protection with Furniture Care
Covers you for manufacturing defects for 2 years.	Covers you for <b>accidental damage</b> up to 3 years for incidents such as household spills, rips, tears and burns. Accidental damage cover begins from the moment your plan starts.
In the event of a problem within this time please call <b>0345 640 0800</b> , or visit an Argos store. Please retain your receipt and order number as proof of purchase.	If you want to purchase Furniture Care visit <b><a href="https://argos.productaftercare.co.uk">https://argos.productaftercare.co.uk</a></b> or go into an Argos store.
Key exclusions applying to both the Manufacturer's Guarantee and Furniture Care include where the fault is due to misuse, abuse, deliberate damage, wear and tear, neglect, use in contravention with the instructions, or if the product has been the subject of unauthorised alterations or commercial use (for full list of exclusions please visit <b><a href="https://argos.productaftercare.co.uk">https://argos.productaftercare.co.uk</a></b> or visit an Argos store for more information). You have up to 45 days post purchase to take out Furniture Care. Terms and conditions apply. Your statutory rights remain unaffected.	

## Register

### For Your Manufacturer's Guarantee

Thank you for choosing Argos Home.  
We hope you love your shiny new things!

To provide you with the best possible after sales service, don't forget to visit **<https://argos.productaftercare.co.uk>** where you can **register** for your guarantee.

Once you've registered, you can upload your receipt to store safely online, alongside details of our after sales support service, ready at hand should you need it.

You can also take out Furniture Care which protects you against accidental damage, from the moment you take the plan out, to keep your new furniture looking newer for longer.

### Register Today

<https://argos.productaftercare.co.uk>