




CUGGL LAUREL STROLLER
care & instruction manual



**IMPORTANT – READ CAREFULLY AND
KEEP FOR FUTURE REFERENCE**

IMPORTANT – READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

Thank you for choosing our product. Please always read all the instructions provided carefully before use and remember the child's safety may be affected if you do not follow these instructions. The stroller is suitable from 6 months up to 15kg (approx. 36 months), never overload.

WARNINGS:

- Never leave the child unattended.
- Ensure that all locking devices are engaged before use.
- To avoid injury ensure that the child is kept away when unfolding and folding this product.
- Do not let the child play with this product.
- This seat unit is not suitable for children under 6 months.
- Always use the restraint system provided and make sure the harness is correctly fitted.
- This product is not suitable for running or skating.
- The parking device shall be engaged when placing and removing the children.
- The maximum permissible loading for the shopping basket is 1kg.
- Any load attached to the handle and/or on the back and/or on the side will affect the stability of the vehicle.
- Use the stroller for only one child at a time.
- Accessories which are not approved by the manufacturer shall not be used.
- Only replacement parts supplied or recommended by the manufacturer/distributor shall be used.
- Do not use if any part is broken, torn or missing
- Avoid placing the pushchair near naked heat sources such as electric bar fires, etc. or where a child could gain access to any other kinds of hazards.

Care and Maintenance

General

This stroller was designed and manufactured with qualified materials and craftsmanship.

Always check and inspect your stroller regularly for:

Worn parts , torn materials or stitching.

Loose screws , bent or broken frame parts.

Broken , damaged or missing parts.

Should any of the above be evident do not use and contact the Helpline : 0345 640 2020 for advice.

Care and Maintenance

Lubricate moving parts regularly, especially the wheels, and lower parts of the chassis that tend to collect dirt.

Fabric parts may be cleaned in accordance with the fabric care labels.

Do not machine wash.

Seat : Sponge clean only.

Canopy / Basket : Hand wash only .


Do not leave the stroller exposed to heat i.e. by a radiator or in direct sunlight .

If the stroller chassis parts have been exposed to salt water, we recommend that they be rinsed down with fresh (soapy) water as soon as possible afterwards.


Do not fold or store the product while wet and never store in a damp environment as this can cause mildew to form.

Contents

Check all parts are present before assembly




Stroller x1



Wheels x2

Name of parts




Assembly

Keep children out of the work area.

1 Assemble the front wheels


- Press down the lock pin on the front tube.
- Insert the front tube into the adaptor on the front wheel until the lock pin has fully engaged into the plastic hole.



1

2 Unfold frame


- Release the red locking catch located on the side of the stroller.
- Open out the stroller by lifting the handles upwards.
- Using your foot, push the rear locking catch down fully to engage the primary lock.
- Place the stroller on a flat surface and ensure the stroller moves freely.



2

3 To operate brakes

- Your stroller has a linked parking brake. To engage brakes simply press down with your foot on the pedal located on the rear wheels.
- To release brakes simply lift the pedal located on the rear wheels with your foot.





3

4

Harness & Buckle

Note: Thread the shoulder straps through the loops to reduce the shoulder strap height if required.

- To fasten the waist harness:
Insert both buckle clips into each side of the buckle until a “Click!” is audible.
- To release the harness:
Squeeze the buckles and pull apart.
- To adjust the buckle:
Adjust the shoulder straps by moving the slides as shown





4

5

To fold the stroller

- See pic A. To release the rear locking catch (1), push the lever in and then lift up with your fingers. Once done lift the second lock (2) upwards with your foot until the lock is released.
- See Pic B. Grip handles and push forward on stroller. Compress the folded stroller and engage the red locking catch located on the side of the stroller.



5

Technical specification

Product title	CUGGL LAUREL STROLLER
Argos Cat. No.	9445635
Supplier Ref. No.	U803HA
Age group	6-36M
Weight suitability	From 6 months up to 15kg
Safety compliance	Complies with EN1888-1:2018
Product weight	4.9 kg
Product unfolded size	L82 x W45 x H105cm
Folded size	L20 x W16 x H120cm

If you encounter any problems with this product please call our customer care team on 0345 640 2020

Produced in China. Argos Limited, 489-499 Avebury Boulevard, Milton Keynes, MK9 2NW. Argos (N.I.) Ltd, Forestside Shopping Centre, Upper Galwally, Belfast, United Kingdom, BT8 6FX. Argos Distributors (Ireland) Limited, Unit 7, Ashbourne Retail Park, Ballybin Road, Ashbourne, County Meath, Ireland