
Le Marais Single Unit





A Safety and Care Advice

Product Details

393/0782 Le Marais Single Unit Grey 945/8938 Le Marais Single Unit White

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• This product has been constructed to be used in the domestic environment only and not for commercial purposes.

Care and maintenance

- Only clean using a damp cloth and mild detergent. Do not use abrasive cleaners.
- Use a dry cloth to clean the product, furniture polish is not recommended.

to its final position (in the same room) as possible.

• Assemble the item as close

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• We do not recommend the use of power drill/drivers for inserting screws


as this could damage the unit. Only use hand screwdrivers.

• Parts of the assembly will be easier with 2 people.

• Dispose of all packaging carefully and responsibly.

• From time to time check that there are no loose screws, nuts or bolts. If there are please re-tighten. • This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Fittings




Hardware





Hinge ×2


Tools required





Panels























Wall fixings are not supplied. Please refer to A Guide To Wall Mounting & Fixings, page 13.


9














A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.



Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualifed tradesperson if you are unsure.

Hints:


- 1: General rule: Always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

walls are made of brick, breeze block, concrete, stone or wood.

You can use one of the following types of wall plug if your


Types of walls

No.1 "General Purpose" wall plug



Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.


No.2 "Plasterboard" wall plug



For use when attaching light loads on to plasterboard partitions.

Care &


Maintenance



No.3 "Cavity Fixing" wall plug


For use with plasterboard partitions or hollow wooden doors.

No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

Safety: Always check the fitting and location to ensure your safety in and around the home. Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.