DOLL HOUSE SPACE SHIP

Assembly & User Instructions - Please keep for future reference 9514092

Cocoland[®]



Important

Age: 3+ years

Important – Please read these instructions fully before assembly or use

These instructions contain important information which will help you get the best from your product and ensure safe and correct assembly, use and maintenance. If you need help or have damaged or missing parts, call the Customer Helpline: 0345 604 0105

ssue 1 - 16/04/21

▲ Safety Information

Important – Please read these instructions fully before assembly or use

General safety

• Adult assembly required!

- Before use, please ensure the item is on a stable and level surface.
- Do not use the item if any part is broken or missing.
 - Young children in play are unaware of potential dangers and hazards, therefore responsible adult supervision is essential.
- Wipe clean only with a soft cloth.
- This product is a toy, Do not allow climb on this product.

Warning

Keep small parts out of the reach of children under 36 months because of possible choking hazard.
Must be secured using a screwdriver.





Note: Each style screw quantity listed above shows the correct amount to complete the assembly. In some cases more fittings may be supplied than required.

Assembly Instructions

Step 1:

Step 2:

1



Assembly Instructions

2









3

Assembly Instructions





Step 6:

5



Step 7:



Care and Maintenance

Periodically check all fittings to ensure that none have come loose.Any loose fittings must be tightened using the correct tool.

٢

0-3

C E CA

6

Not suitable for children under 3 years due to small parts, choking hazard.

If you need help or have damaged or missing parts, call the **Customer Helpline:** 0345 604 0105 Produced for Chad Valley Toys. *Country of origin:* Made in China. *Address:* 489-499 Avebury Boulevard, Central Million Keynes,MK9 2NW. www.argos.co.uk/chadvalley