

Koba

habitat



Spare Parts

 www.argos-support.co.uk

 Help@ClickSpares.co.uk

 0370 112 1928

Customer Support

 0345 640 2020



Safety and Care Advice

Product Details

HAB KOBA RATTAN CHAIR 9533279

Care and maintenance

- Only clean using a damp cloth and mild detergent. Do not use abrasive cleaners.
- Use a dry cloth to clean the product, furniture polish is not recommended.
- From time to time check that there are no loose screws, nuts or bolts. If there are please re-tighten.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Additional Guidance

- This product is compliant to EN 12520, EN 1022
- Maximum user weight 110 kg
- This product has been supplied with additional felt feet pads that can be used to help level up furniture on uneven floors

Sainsburys Argos Care Guide

- Periodically check and re-tighten feet where required.
- Keep sofa/chair out of direct sunlight to avoid discolouring.
- Do not place the furniture in a conservatory, excessively dry or humid conditions.
- Avoid sharp items such as toys, jean rivets and buckles coming into contact with the upholstery as these can easily snag, tear or pull the fabric.
- To maintain the appearance and durability of your suit, restrain children and pets from climbing and jumping on the sofa.
- Rattan is natural material and can display natural marks and characteristic such as colour deviation. These are natural features not faults.