
OAKLEY - LARGE TV UNIT ASSEMBLY INSTRUCTIONS

Thank you for purchasing the **LARGE TV UNIT.**
Please read the instructions carefully to ensure safe operation of the product.




Size: (W)1300 x (D)390 x (H)495mm

PLEASE READ this sheet prior to assembly to familiarise yourself with the various stages of construction.


Carefully open the pack supplied and check the contents against the parts and fittings check list. Do not destroy any of the packaging until you are certain that you have all the necessary parts for the assembly.

CAUTION: There are small components used in the construction of this unit. These loose items should be kept away from young children whilst assembling your unit to avoid the danger of choking hazards.

Tools Required



Person Required



Approximate Assembly Time



IMPORTANT - READ CAREFULLY - RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

INFORMATION

- This product is intended for a maximum weight of **30kgs** and shelf load capacity **3kg** each. Do not exceed this weight.
- Due to the size of this product we recommend that is assembled in the room intended for use.
- When you ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly
- Unwrap all packaging materials and place the components on top of the carton box or not on a clean floor to prevent it from scratching.
- Check the pack and make sure you have all the parts listed.
- Ensure that this product is fully assembled as illustrated before use.
- Check all screws or bolts are tightened and inspect regularly.
- This product should only be used on firm, level ground.
- Keep small parts out of reach of children.
- Make sure the legs remain in contact with the ground.
- Tools not included.

WARNINGS

- DO NOT use power tools to construct this product.
- DO NOT tighten screw until fully assembled.
- DO NOT over tighten screw or bolts.
- DO NOT use this product if parts are missing, damage or worn.
- DO NOT stand or sit on this large tv unit.

CARE INFORMATION


- Never use scourers, abrasives or chemical cleaners.
- To clean wipe with a sponge and soapy water. Do not use solvent based cleaners or detergents as they can bleach or damage the product.

Please check the pack contents before assembling the product. If any components are missing, please contact your retailer. The fittings pack contains small items that should be kept away from small children.


Parts

CODE	PART NAME	QTY
A	Side Panel (L) (30 x 375 x 470mm)	1
B	Side Panel (R) (30 x 375 x 470mm)	1
C	Top Panel (24 x 390 x 1300mm)	1
D	Bottom Panel (15 x 374 x 1210mm)	1
E	Partition Panel (L) (15 x 373 x 395mm)	1
F	Partition Panel (R) (15 x 373 x 395mm)	1

CODE	PART NAME	QTY
G	Fixed Shelf Panel (15 x 350 x 584mm)	1
H	Adjustable Shelf Panel (12 x 349 x 297mm)	2
I	Bottom Front Panel (15 x 60 x 1210mm)	1
J	Door Panel (20 x 290 x 387mm)	2
Y	Backply Panel (2.5 x 318 x 420mm)	2
Y1	Backply Panel (2.5 x 598 x 210mm)	2




Fixings (to scale)



4x
D6.3 x 40mm
a
Unitar Screw

16x
D8 x 30mm
b
Wooden Dowel

16x
M5 x 29mm
c
Minifix Bolt



5x
5 x 8 x 13.5mm
d
Nail Leg

16x
M3.5 x 15mm
e
Csk Screw


2x
M4 x 25mm
f
Handle Screw

16x
D12 x 15mm
g
Minifix Cam


8x
D5 mm
h
Shelf Support

40x
i
Nail Pin


Fixings (not to scale)




2x
j
Metal Round Handle




4x
(7/8)
k
Hinges



2x
l
Door Stopper





1x
M4
m
Allen Key



Layout Parts on Soft Surface


STEP 1







Parts Required	Qty
Panel (A)	1
Panel (B)	1
Panel (D)	1
Panel (E)	1
Panel (F)	1
Panel (G)	1
Panel (I)	1

STEP 2







Don't screw too deep



Parts Required	Qty
Panel (A)	1
Panel (B)	1
Panel (C)	1
Panel (E)	1
Panel (F)	1


STEP 3







Parts Required	Qty
Panel (J)	2

STEP 4










Parts Required	Qty
Panel (E)	1
Panel (F)	1
Panel (G)	1

STEP 5

Allign the panel as shown and attach panel to other panel accordingly.











Parts Required	Qty
Panel (D)	1
Panel (E)	1
Panel (F)	1
Panel (G)	1
Panel (I)	1

STEP 6












Parts Required	Qty
Panel (A)	1
Panel (B)	1


STEP 7






STEP 8







g




8 x






Parts Required	Qty
Panel (C)	1


STEP 9





i



40 x









Parts Required	Qty
Panel (Y)	2
Panel (Y1)	2


STEP 10

h




8 x






STEP 11




Parts Required	Qty
Panel (H)	2


STEP 12




A. Lateral adjustment



B. Front-to-Back adjustment




C. Vertical Adjustment



f 1 x


e 4 x

j 1 x




Parts Required	Qty
Panel (J)	1


STEP 13




A. Lateral adjustment



B. Front-to-Back adjustment




C. Vertical Adjustment



f 1 x

e 4 x

j 1 x




Parts Required	Qty
Panel (J)	1

Complete Assembly


Your **OAKLEY LARGE TV UNIT** is now completely assembled

Periodically check to ensure that the components are in their proper position, free from damage. Also, make sure the connectors are tight and secure.



Represented by:
Authorised Rep Compliance Ltd
71 Lower Baggot Street
Dublin
D02 P593
Ireland
www.arccompliance.com

Keep instructions for future reference



Supplied By
GFW The Furniture Warehouse
Waterside Distribution Centre
Waterside Business Park
Johnson Road
Lancashire
BB3 3RT
www.gfwlimited.co.uk