Long Life Lamp Company

Product Instructions

Supplier's Name: Long Life Lamp Company
Supplier's Address: T2 Arundel Rd Uxbridge UB8 2RP UK
Production Description: Set of 3 USB Rechargeable LED Wax Coiled Fairy Flameless Candles with Remote Control
Model No.: WAX05

• General Information

G (A↑G)


IP20

TYPE OF LIGHT SOURCE

Lighting technology used	**LED**
Non-directional or directional	**Non-directional**
Cap-type (or other electric interface)	**Built-in**
Mains or non-mains	**Non-mains (4.5V DC)**
Dimmable	**No**

GENERAL PRODUCT PARAMETERS

Energy consumption in on-mode	**0.06 kWh/1000h**
Useful luminous flux	**2.6 LM**
Beam angle correspondence	**90 °**
Correlated colour temperature	**Warm White 2200 K**
On-mode power	**0.06 W**
Outer dimensions	**77 x 98 mm / 77 x 122 mm / 77 x 148 mm**
Material	**Wax + Plastic**
Colour	**Red + White**
Remote Control Range	**3 - 5 m**
Battery	**Built-in 400mAh Li-ion Rechangeable Battery Per Candle**
Charging Time	**2 Hours**
Working Time	**12 - 13 Hours**
Battery Life	**Charge and discharge around 300-400 times**



EN60598-1 CE UK CA RoHS

5 056151 744121

Please fully charge before use!

Warning! Keep Away From Heat

Please note: For Indoor Use ONLY!
LED lamp not user-replaceable



How to illuminating the candle with remote control

Candle will illuminate until you manually move the switch to OFF.

ON-OFF button: illuminate the candle ON-OFF.
(NOTE:Before you use the remote control, switch the ON-OFF button at the buttom of candles.)

Timer: Set ON/OFF automatic timer feature,set 2H/4H/6H/8H.
*For example: set 2H at:20:00,it will automatically shutdown at 22:00,will be automatically open at 20:00 next day at 22:00 then automatically shutdown. It will cycle every 24 hours.

Mode: Candle is NON-flicker flame; Light is flicker flame.

Brightness Control: Left button to lower the brightness,right button to increase brightness.

More tips:
*Pull out the protect sheer before use.
*If the battery of remote control runs out,you may pull out the battery tray then replace a new button cell battery.

Care and Maintenance
*Clean as needed with a soft,dry or slighty damp cloth.
*Keep out of direct sunlight,away from heat sources and out of extreme temperatures of your candle may soften or melt.
*When not in use for an extended period of time,please remove the batteries.
*Use fresh batteries of the required size and type only. Do not insert mix old and new.
*Place the candle on a protective base, on a candle holder or in a lantern to protect furniture from wax deposits.

Caution and Warnings

1. This candle is made of real wax and is flammable. Do not attempt to light this candle, which couldresult in personal injury or damage to the light and its components.
2. Warning! This product contains small parts, which if removed, can pose a choking hazard. Keep away from small children.