

User Manual

Parts Enclosed:

- (1) Bulb (complimentary)
- (2) Lampshade Ring
- (3) Lampshade
- (4) Pedestal

Assembly/User Instructions:


1. Carefully unpack the lamp, then place on a stable and flat surface without plugging in.
2. Flip the lampshade (3) 180 degrees when unpacking, then place it over the pedestal (the lamp cup).
3. Secure the lampshade with the lampshade ring (2).
4. Screw the bulb (1) into the pedestal (4).
5. Plug in and operate the switch to turn on.

(Note: If the lamp will not illuminate please contact our customer service or consult a qualified electrician.)

Care Instructions:

1. Please take the lampshade to the outdoor to shake it when unpacking. At this time, there will be feathers falling. Don't worry, it is normal. Just shake off the broken feathers is ok.
3. Never fit bulbs of a higher wattage than those specified on the label.
4. Clean with soft or dry cloth.
5. Always avoid the use of harsh chemical or abrasive cleaners as they may cause damage to the lamp.

*SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

**WARNING**

Don't move the copper inside the lamp cap.



User Manual

Parts Enclosed:

- (1) Bulb (complimentary)
- (2) Lampshade Ring
- (3) Lampshade
- (4) Pedestal

Assembly/User Instructions:


1. Carefully unpack the lamp, then place on a stable and flat surface without plugging in.
2. Flip the lampshade (3) 180 degrees when unpacking, then place it over the pedestal (the lamp cup).
3. Secure the lampshade with the lampshade ring (2).
4. Screw the bulb (1) into the pedestal (4).
5. Plug in and operate the switch to turn on.

(Note: If the lamp will not illuminate please contact our customer service or consult a qualified electrician.)

Care Instructions:

1. Please take the lampshade to the outdoor to shake it when unpacking. At this time, there will be feathers falling. Don't worry, it is normal. Just shake off the broken feathers is ok.
3. Never fit bulbs of a higher wattage than those specified on the label.
4. Clean with soft or dry cloth.
5. Always avoid the use of harsh chemical or abrasive cleaners as they may cause damage to the lamp.

*SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

**WARNING**

Don't move the copper inside the lamp cap.



User Manual

Parts Enclosed:

- (1) Bulb (complimentary)
- (2) Lampshade Ring
- (3) Lampshade
- (4) Pedestal

Assembly/User Instructions:


1. Carefully unpack the lamp, then place on a stable and flat surface without plugging in.
2. Flip the lampshade (3) 180 degrees when unpacking, then place it over the pedestal (the lamp cup).
3. Secure the lampshade with the lampshade ring (2).
4. Screw the bulb (1) into the pedestal (4).
5. Plug in and operate the switch to turn on.

(Note: If the lamp will not illuminate please contact our customer service or consult a qualified electrician.)

Care Instructions:

1. Please take the lampshade to the outdoor to shake it when unpacking. At this time, there will be feathers falling. Don't worry, it is normal. Just shake off the broken feathers is ok.
3. Never fit bulbs of a higher wattage than those specified on the label.
4. Clean with soft or dry cloth.
5. Always avoid the use of harsh chemical or abrasive cleaners as they may cause damage to the lamp.

*SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

**WARNING**

Don't move the copper inside the lamp cap.

