Assembly instruction

Ax1



Bx4 Cx1 Dx12








Ex4



1



2

