


schallen.

Double Head Fan

INSTRUCTION MANUAL

Model: SCH1322-BLK / SCH1320-WH



Please retain for
future reference

CE UK RoHS 

Made in China

Thank you for choosing this **Schallen Double Head Fan**. Designed to deliver efficient, smooth airflow for everyday comfort, this product has been engineered to meet UK safety and performance expectations. Please read this user guide carefully before use and retain it for future reference.



SAFETY WARNINGS

General Safety

- This product is not a toy. Keep out of reach of children.
- Children under 14 years of age should only use this product under adult supervision.
- **Do not** insert fingers, hair, clothing or any objects into the fan grilles while the fan is operating.
- **Do not** use the fan if it has been dropped, damaged, or shows signs of malfunction.
- For indoor use only.



Electrical Safety


- This fan is powered via USB-C (5V DC).
- Use only the supplied USB-C cable or a certified equivalent.
- **Do not** operate the fan with wet hands or expose it to water or moisture.
- Always disconnect the fan from the power supply before cleaning or when not in use.

Placement & Use

- Place the fan on a stable, flat surface.
- **Do not** cover the air inlet or outlet.
- **Do not** use the fan near flammable materials or in explosive environments.
- Ensure adequate ventilation around the fan during operation.

PRODUCT OVERVIEW

The Double Head Fan is a compact desktop fan with two independently adjustable fan heads, designed to deliver improved air circulation while taking up minimal desk space.



Power & Speed Controls

This fan is operated using three buttons:

the **Power Button**, **Button A**, and **Button B**.

- The Power Button controls both fan heads together.
- Each short press cycles through the speed settings: **Low → Medium → High → Off**.
- **Button A** controls the **upper fan head**, and **Button B** controls the **lower fan head**.
- Each short press cycles the selected fan head through the same settings: **Low → Medium → High → Off**.
- **Press and hold** any button at any speed to switch the corresponding fan head (or both fan heads when using the Power Button) off immediately.

Fan Head Adjustment

- Each fan head can be **tilted up/down** and **rotated left/right** manually.
- Adjust gently by hand.
- **Do not** apply excessive force when positioning the fan heads.

Charging & Power Supply

- Connect the supplied **USB Type-C cable** to the charging port on the fan base.
- Connect the other end to a USB power source (computer, power bank, or USB mains adaptor).

TROUBLESHOOTING

FAULT	SOLUTION
Fan does not operate	Check the USB cable is securely connected to the power source.
Airflow is weak	Remove any obstruction and check the power supply.
Fan is noisy	Switch off the fan and reposition the fan heads correctly.

BOX CONTENTS

- Double Head Fan × 1
- USB Type-C Charging Cable × 1
- Instruction Manual × 1

SERVICE & DISPOSAL

- **Do not** attempt to repair the fan yourself.
- Contact an authorised service centre for repairs.
- Dispose of the product in accordance with local electrical waste regulations.

Disposing of the Packaging

Please dispose of all packaging materials responsibly and in accordance with local recycling guidelines.


- Separate the materials by type.
- Place paperboard and cardboard in the paper recycling bin.
- Dispose of plastic materials in the appropriate recycling container.

Whenever possible, recycle the packaging to help protect the environment.



Meaning of crossed-out wheeled dustbin:

- Do not dispose of electrical appliances as unsorted municipal waste; use separate collection facilities.
- Contact your local government for information regarding available collection systems.
- If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and enter the food chain, damaging health and well-being.
- When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposal at no charge.



schallen.

Imported By:

NETAGON LTD

Unit 4, Chandlers Court, Picow Farm Road,
Runcorn, Cheshire, WA7 4UH