

Very happy?

Not so happy?

Thanks for your purchase, how was it for you? We would love to hear your feedback. Please leave a product review on the website you bought from.

HEATED ELECTRIC THROW

Dreamcatcher

● **NOTE:** On initial use and after washing, it is recommended that the throw is operated for 2 hours to ensure it is completely dry. Ignore any slight odour that may occur on first use.

● Do not sleep with the controller set to maximum heat. Switch off when the heating is no longer required – do not leave on indefinitely. Unplugging the throw from the mains when not in use.

● Drape the throw over the shoulders and smooth out to remove any creases. The controller should be positioned close to hand so that the temperature and time can be adjusted without walking around with the throw on.

● Press the temperature button to set the desired temperature from 1 to 9.

● Press the fast heat button to set the desired time from 1 to 60 minutes.

● The controller has 9 temperature settings, 1 being the lowest range and 9 being the highest range in temperature. These can be attained by pressing the temperature setting button.

● Press the fast heat button to set the desired time from 1 to 60 minutes.

● The timer on the controller can be set from 1-12 hours by pressing the timer button.

Very happy?

Not so happy?

Thanks for your purchase, how was it for you? We would love to hear your feedback. Please leave a product review on the website you bought from.

HEATED ELECTRIC THROW

Dreamcatcher

● Press the temperature button to set the desired temperature from 1 to 9.

● Press the fast heat button to set the desired time from 1 to 60 minutes.

● The timer on the controller can be set from 1-12 hours by pressing the timer button.

Very happy?

Not so happy?

Thanks for your purchase, how was it for you? We would love to hear your feedback. Please leave a product review on the website you bought from.

HEATED ELECTRIC THROW

Dreamcatcher

● This is designed to be used as a throw only. It is recommended to connect to the standard UK mains supply 230V/240V.

● Plug the mains lead into the blanket socket for it to be ready to heat up.

● Press the On/Off button to make the blanket work.

Very happy?

Not so happy?

Thanks for your purchase, how was it for you? We would love to hear your feedback. Please leave a product review on the website you bought from.

HEATED ELECTRIC THROW

Dreamcatcher

● Press the temperature button to set the desired temperature from 1 to 9.

● Press the fast heat button to set the desired time from 1 to 60 minutes.

● The timer on the controller can be set from 1-12 hours by pressing the timer button.

Very happy?

Not so happy?

Thanks for your purchase, how was it for you? We would love to hear your feedback. Please leave a product review on the website you bought from.

HEATED ELECTRIC THROW

Dreamcatcher

Very happy?

Not so happy?

Thanks for your purchase, how was it for you? We would love to hear your feedback. Please leave a product review on the website you bought from.

HEATED ELECTRIC THROW

Dreamcatcher

Very happy?

Not so happy?

Thanks for your purchase, how was it for you? We would love to hear your feedback. Please leave a product review on the website you bought from.

HEATED ELECTRIC THROW

Dreamcatcher

FREQUENTLY ASKED QUESTIONS

Can I sit on the throw?

■ No do not sit on the throw as this could potentially cause the throw to malfunction or not work correctly. This product is simply an over blanket and not an under blanket.

Can I put the throw in the washing machine?

■ Yes but make sure you disconnect the controller from the throw before washing and follow the washing instructions on the label.

Can I use this throw for a child or baby.

■ No this product is strictly for adult use only and under no circumstances should this item be used by or for children.

I have problem with the throw as it does not seem to heat up evenly.

■ If you are experiencing any issues with the product please do not use and kindly get in touch with us at help@futuradirect.co.uk as we are glad to help with any problems that may occur with the product.

I am not sure how to use the settings on the controller.

■ If you are unsure of any settings on the controller, please refer to the manual or alternatively contact us at help@futuradirect.co.uk

Can I use the throw if wet or slightly damp.

■ Under no circumstances must you use if the throw is wet or damp as this could cause an electrical accident.

What can I do if a spill a drink on the throw?

■ Switch the throw off immediately as electrical items and liquids are dangerous if in contact and could cause an electric shock or an electrical accident. If you need to clean the throw, remember to disconnect from the cable and controller before cleaning the throw.

Can I leave the throw switched on unattended?

■ Only have the throw switched on while in use and never leave the item unattended.

Does the throw come with a guarantee?

■ Yes, the product comes with a 2 year guarantee which means if the item stops working within that period we can send a replacement.

How do I get in contact with the seller.

■ You can contact us direct at help@futuradirect.co.uk or alternatively through the website you purchased the item.

Very happy?

Not so happy?

Thanks for your purchase, how was it for you? We would love to hear your feedback. Please leave a product review on the website you bought from.

HEATED ELECTRIC THROW

Dreamcatcher

Dreamcatcher ELECTRIC HEATED THROW BLANKET

Very happy?

Not so happy?

Thanks for your purchase, how was it for you? We would love to hear your feedback. Please leave a product review on the website you bought from.

HEATED ELECTRIC THROW

Dreamcatcher

www.futuradirect.co.uk

We Futura Direct Ltd. England DN6 7AY declare that the electric heated throw blanket is exclusively manufactured for Futura Direct Ltd. and has been manufactured according to our quality assurance procedures.

Very happy?

Not so happy?

Thanks for your purchase, how was it for you? We would love to hear your feedback. Please leave a product review on the website you bought from.

HEATED ELECTRIC THROW

Dreamcatcher

USER MANUAL

Please read and retain for future reference.

Very happy?

Not so happy?

Thanks for your purchase, how was it for you? We would love to hear your feedback. Please leave a product review on the website you bought from.

HEATED ELECTRIC THROW

Dreamcatcher

Very happy?

Not so happy?

Thanks for your purchase, how was it for you? We would love to hear your feedback. Please leave a product review on the website you bought from.

HEATED ELECTRIC THROW

Dreamcatcher

Very happy?

Not so happy?

Thanks for your purchase, how was it for you? We would love to hear your feedback. Please leave a product review on the website you bought from.

HEATED ELECTRIC THROW

Dreamcatcher

Very happy?

Not so happy?

Thanks for your purchase, how was it for you? We would love to hear your feedback. Please leave a product review on the website you bought from.

HEATED ELECTRIC THROW

Dreamcatcher

Dreamcatcher

Electric Heated Throw Blanket User Manual

Please read and retain for future reference

Thank you for choosing this product from our Dreamcatcher range, we certainly hope you like your new throw, if you are unhappy or would like to get in touch and speak to a customer service adviser, please do not hesitate to contact us. We are here to make sure you are satisfied with the product.

SPECIFICATIONS		With controller
DHTG-2	Size:	160 x 120 cm
DHTBK-2	Size:	160 x 120 cm
DHTGN-2	Size:	160 x 120 cm
DHTN-2	Size:	160 x 120 cm
DHTNB-2	Size:	160 x 120 cm
DHTS-2	Size:	160 x 120 cm
DHTGO-2	Size:	160 x 120 cm
DHTP-2	Size:	160 x 120 cm
DHTGXL	Size:	180 x 130 cm
DSFDG	Size:	160 x 120 cm
DSFB	Size:	160 x 120 cm
DSFNB	Size:	160 x 120 cm
DSFG	Size:	160 x 120 cm

Controller code for all blankets:

ZDHT-2/CONTROL



Contents

- Soft throw with controller.
- Manual.

Features

- Removable controller.
- Washable (remove controller before washing) check label for washing temperature.
- Various heat settings from low temperature to high.
- Timer function.

Getting started

- Remove throw from box.
- Remove all packaging from item.

SAFETY INSTRUCTIONS

Important!

- This electric heated throw is designed as an over blanket only. Please do not sit on the blanket as it is not designed for that purpose and this could result in the blanket not functioning, it could also cause the blanket to overheat.
- Do not fold or scrunch the throw as this could also cause over heating and the blanket to malfunction.
- This product should not be used for children and people who are not mentally or physically able to work this device.
- Do not use the throw with anyone sensitive to heat.

- Do not allow children to play with the throw.
- This product is not a toy.
- Avoid extensive use of this product as it could cause over heating of the body.
- Do not insert pins or sharp objects into the throw.
- Do not use if wet and do not use near water.
- Always check the product for damage or tears, if there is any damage do not use and get the product looked at by an electrical engineer. If the product is under guarantee, then we are happy to send you a replacement so please get in touch.
- This product is intended for household purposes only and should not be used for industrial or commercial purposes.
- Do not use if the controller or cable are damaged or malfunctioning.

CARE AND MAINTENANCE

Before cleaning

Disconnect the throw from the mains supply, and then disconnect the controller from the throw. Store the controller away carefully.

Cleaning

Do not dry clean this throw. The throw has waterproof heating elements making it safe to immerse in water and wash by hand or machine. Always remove the controller first – do not allow any part of the controller to be immersed in any liquid.

Hand wash

After disconnecting the controller, immerse the throw in a luke-warm, mild detergent, water solution. Soak for five minutes, remove and gently squeeze out as much water as possible (DO NOT WRING THE THROW). Rinse in clean water, squeeze out as much as possible (again without wringing).

Machine Wash

With the controller detached the throw can be washed in a machine (size permitting). Wash on WOOL or DELICATES cycle with a neutral detergent or mild soap powder at a wash temperature of 30°C. Do not use high speed or extra spin cycles.

Drying

Drape the throw over a clothes line to dry – do not use pegs to secure the throw. Allow to dry naturally – do not use any form of direct heat such as a hair dryer or heater. Ensure that the throw and its connector are fully dry before reconnecting the controller and using.

Damage Check

The throw, controller and cable must be regularly checked for damage. If any damage or wear is found, the product must be checked by a qualified engineer.

DECLARATION OF CONFORMITY

We Futura Direct Ltd, declare that the electric heated throw has been manufactured according to our full quality assurance procedures.

The declaration is to certify that it conforms to CE, EMC, WEEE and RoHS directives.



Mr. Sean Parlour-Richardson, UK QA Manager. Please read the following carefully Futura Direct Ltd. and/or its distributor have provided the parts list and assembly diagram as a reference tool only.

Neither Futura Direct Ltd. or its distributor makes any representation or warranty of any kind to the buyer that he or she is qualified to do any repairs or replace any parts of this product. Futura Direct Ltd. and its distributor expressly state that all repairs or parts replacement should be done by certified or licensed technicians. The buyer assumes all risk and liability arising out of his or her repairs or parts replacement to the original product.

ENVIRONMENTAL PROTECTION



Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

24 MONTHS LIMITED WARRANTY

Here at Futura we are confident that you will enjoy many hours of pleasure from your product. However, if within 24 months from the date of purchase you experience any problems due to defects in materials or manufacture, please send an email to help@futuradirect.co.uk

Should your product develop a fault please follow these steps immediately:

- Send an email to help@futuradirect.co.uk for any help.
- We will replace any defective product that is in warranty due to defective materials or workmanship.
- We will NOT replace any product that has faults due to accidental damage, abuse or from failure to follow the instructions.
- This does not affect your statutory rights.



QUICK
HEAT-UP



LED
DISPLAY



9 HEAT
SETTINGS



OVERHEAT
PROTECTION



DETACHABLE
CORD



MACHINE
WASHABLE

Dreamcatcher HEATED THROW BLANKET

Thanks for your purchase, how was it for you? We would love to hear your feedback. Please leave a product review on the website you bought from.

Very
happy?



Not so
happy?

