# How to fold away

1.

Leave the unit in the middle of the mat.

2.

Pull the front and back of the mat together and hold in place with the yellow hook and loop fastener.

3.

Attach the sides (as shown) together using the white hook and loop fastener.

4.

Attach the sides (as shown) together using the black hook and loop fastener.

5.

x 10

CHAD VALLEY®

WARNINGS
- Keep away from fire.
- Adult supervision required.
- For indoor use only.
- Charging of the product to be carried out by adults only.
- Do not immerse the product in water.
- Wipe clean with a damp cloth prior to use and storage.
- Adults should regularly inspect the product for damaged or broken parts.
- Retain these instructions for future reference.

CE

How to use

Switch the unit to ON.
(as per visual)

ON **OFF**

Catalogue n...

You can place a ball onto the unit and press the big button on the front to float the ball
or you can press the big button and place the ball into the air flow.

Charging

Insert the micro USB cable into
the unit and then connect to your
own USB plug.

USB Plug not supplied.

8hrs

Charging.   Charged.

Ensure the unit is in the **ON** position when charging.
Charging the unit to full capacity will take approximately
8 hours.

When charging the unit the light will flash. Once fully
charged the light will remain constant.
(As a safety measure the unit will not power on when
charging).

Remove the micro USB cable before use.

ON **OFF**

Catalogue n...