Matrix Sideboard

hygena

Dimensions

Width – 80cm

Depth – 40cm

Height – 70cm

Important – Please read these instruction fully before starting assembly

If you need help or haved amaged or missing parts, call the Customer Helpline : 03456 400800

⚠ Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.

• We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

Glass safety

· Keep these instruction for future reference.

· Imported by:
Argos Ltd.

489-499 Avebury Boulevard.
Saxon Gate West.
Central Milton Keynes.
Mk9 2NW

· If the glass is chipped or broken, stop using the product and consult the Manufacturer or Supplier.

· Batch No:

· Date of Manufature:
· Type of glass used: 5mm and 8mm toughened glass.

Warnings

(a) Do not place very hot or very cold items on the glass surface(s) unless adequately thick mats are used to prevent such items from coming into contact with the glass.
(b) Do not sit or stand upon the glass surface(s).

(c) Do not use the glass as a chopping surface. Do not strike the glass with hard or pointed items.

(d) When cleaning glass panels use a damp clothe or leather with washing up liquid or soft soap if necessary, do not use washing powders or any other substance containning abrasives since these substances scratch glass.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components – Panels

1	Glass Top x 1 (80 x 40cm)

2	Top panel x 1 (80 x 40cm)

3	Metal tube x 4 (60 x 2.5cm)

↑ Unfinished edge

4	Left side panel x 1 (39.9 x 60cm)

↑ Unfinished edge

5	Right side panel x 1 (39.9 x 60cm)

7	Feet x 4 (2.5 x 3.5cm)

6	Bottom panel x 1 (80 x 40cm)

8	Back Panel x 1 (74 x 61.5cm)

9	Shelf panel x 1 (71 X 37cm)

10	Glass door x 2 (59.2 x 35cm)

Components − Fittings

Please check you have all the fittings listed below

Note : The quantities beloware the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

|		
A 60mm Screw x 8	**B** 35mm Cam pillar x 4	**C** 30mm Plastic dowel x 8
D Door catch set x 1	**E** 15mm Cam x 4	**F** 45mm Screw x 4
G 15mm Screw x 16	**H** Supporter x 4	**I** Easy door assembly spring x 4
J Hinge set x 2	**K** Counter plate set x 2	**L** Wall plug x 1
M Wall strap x 1	**N** 15mm Screw x 1	**O** 25mm Screw x 1

Tools required

Cross head screw driver
(not included)

Hammer
(not included)

Ruler− Usethisrulertohelpcorrectlyidentifythescrews

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

Assembly Instructions

Step1

Attaching screws

Assemble 4 pcs of screws **A** onto top glass [1].

Step2

Attaching panel

Assemble top panel [2] onto top glass [1].

Step3

Attaching metal tube

Assemble 4 pcs of metal tube [3] onto the screw **A**.

Assembly Instructions

Step4

Attaching cam pillar

Assemble 4pcs of cam pillars **B** onto top panel 2 .

Step5

Attaching door catch set

Assemble door catch set **D** onto top panel 2 .

Step6

Fitting dowels

Insert 8 pcs of plastic dowels **C** into panel 4 5 .

# Assembly Instructions

Step7

Attaching cams

Attach side panel 4 5
onto top panel 2
with cam **E** to tighten.

Unfinished edge

Step8

Attaching screws

Assemble 4 pcs of
screws **A** onto metal
tube 3 .

Assembly Instructions

Step9

Attaching panel

Two people are required here.

Assemble bottom panel 6 onto panels 4 & 5 .

Assemble 4 pcs of screws **F** onto bottom panel 6 .

Unfinished edge

Step10

Attaching foot

Assemble 4 pcs of foot 7 onto screws **A** .

7

Assembly Instructions

Insert door assembly spring

a:

Insert 2 pcs of door assembly spring **I** to the top 2 .

b:

Insert 2 pcs of door assembly spring **I** to the bottom 6 .

Step12

Attaching back panel

Use screws **G** to fix back panel 8 otno the unit.

Unfinished edge

8

Assembly Instructions

Step13

a:

Inserting shelf support

Insert 4 pcs of shelf support **H** in the proper position of panel 4 5 .

b:

Inserting shelf

Insert the shelf 9 onto unit.

Step14

Attaching hinge set

Attach part **J** onto bottom board 6 .

Assembly Instructions

Step15

Attaching door

Please make sure the part **J** as shown is the correct one for assembly at this stage.

CAUTION:
Before tighten the glass with part **J**, please ensure the part **J** align to the edge of glass door.

Frosted side

Step16

Attaching door

a :Insert part **J** into top panel 2.

b :Slide glass door into part **J** onto bottom panel 6.

c :
Before tighten the glass with part **J**, please ensure the part **J** align to the glass door 10.

Frosted side

a:

b:

c:

Assembly Instructions

Step17

Attaching door

a :Insert part **J** into top panel 2 .

b :Slide glass door into part **J** onto bottom panel 6 .

c :
Before tighten the glass with part **J** , please ensure the part **J** align to the glass door 10 .

2

Frostedside

a:

10

6

b:

c:

Step18

Attaching plate

Attach plate **K** to the glass door at the position as shown.

K

10

K

10

Frosted side

Unfrosted side

Assembly Instructions

Step19

Fixing to wall

Note: It would be useful to ask someone to help you at this stage.

It is strongly recommended that the unit is attached to the wall using Wall strap **O** .

⚠️

Important: When drilling into walls always check that there are no hidden wires or pipes etc. Make sure that the screws and wall plugs supplied are suitable for supporting the unit. Consult a qualified tradesperson if you are not sure.

a : With help, place the unit in the intend position.

Fix Wall strap **M** onto Top back panel 8 by using the Screw **N** .

b : Drill a hole in the wall at an appropriate position and insert Wall plug **L**

To secure the unit, fix Wall strap **M** to the wall using Screw **O**

Assembly Instructions

**Assembly is
complete**.

MAX:20 kgs

If you need help or haved amaged or missing parts, call the CustomerHelpline : 03456 400800

A Guide to - Wall Mounting & Fixings

⚠ **Important:** When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

1: General rule: ⚠ Always use a larger screw and wall plug if you are not sure.

**2:** Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.

4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls

You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 **"General Purpose"** wall plug

Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 **"Plasterboard"** wall plug

For use when attaching light loads on to plasterboard partitions.

No.3 **"Cavity Fixing"** wall plug

For use with plasterboard partitions or hollow wooden doors.

No.4 **"Cavity Fixing-Heavy Duty"** wall plug

For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 **"Hammer Fixing"** wall plug

For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 **"Shield Anchor"** wall plug Heavy loads

For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

⚠ Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.