Cover for 8ft/10ft Trampoline
Assembly Instructions

Parts List

Description	Illustration	Qty
Cover		1

WARNING

- Dispose all polyethylene bags and packing material properly and keep them away from children.
- Familiarize yourself with the assembly instructions before attempting to assemble.
- The enclosure should be folded and placed on the mat so that it is also protected by the cover. This will ensure it is readily available for future use.
- Adult assembly required.
- Please keep trampoline cover away from fire.
- When the trampoline cover is in place do not jump/play on the trampoline as you could slip and this could result in injury.
- The trampoline cover is not a toy.
- The trampoline cover is to be used in the manner in which it was intended for.
- Please retain these assembly instructions for future reference.
- The cover is intended to protect the trampoline from external factors such as pollution, leaves, dirt and bird dropping.
- To prolong the usable life of your trampoline, use the cover when not in use to reduce exposure to the pad/mat from UV/sunlight.
- Do not obstruct the holes in the centre which are used to drain excessive water build up.

NOTES

- This cover is not intended to be water proof.
- In extreme weather condition such as heavy or long term rain or snow, the trampoline should be dismantled and stored properly to protect it from weather damage and corrosion.

For Customer Service, please call (+44) 03300 904420
or visit www.sportspowerfit4kids.com

Monday – Friday 8:00 AM – 5:00 PM

Sportspower Ltd.

20/F, Parkview Centre, 7 Lau Li Street, Causeway Bay, Hong Kong

www.sportspowerltd.net

STEP 1

Place cover on top of trampoline.



STEP 2

The cover is designed to fit both 8FT and 10FT trampolines. Wrap the appropriate elastic band around the trampoline frame. Tie the straps around the legs as shown in the enlarged diagrams. Use the inner straps for the 8ft trampoline and the outer straps for the 10ft trampoline.





STEP 3

Straighten out the cover and pull down the sides.