GUARANTEE

Your HARRY LIME smartwatch is guaranteed against defects of material and manufacture for 24 months from date of purchase. There are a few things not covered by the guarantee including batteries, straps, damage caused from accidents or mishandling or water penetration. This guarantee does not affect your statutory rights. We are confident you'll love your new smartwatch, but if you do have any issues under the terms of the guarantee, please get in touch and we will guide you through the returns process.

HOW TO CARE FOR YOUR SMART WATCH

Please do not wear your smartwatch whilst applying sprays or creams. Do not allow contact with any corrosive agents such as paint, solvents or adhesives as this may affect the case and finish. Do not try to replace or disassemble battery.

STRAP CARE To keep your strap looking good, please clean it regularly with mild soap and water to remove any dirt. White straps can need extra care, please visit our website to see our tips for keeping them looking their best. When you are not wearing your smartwatch, we recommend you store it in its gift box.

STEP COUNTER Smartwatches use multiaxis inertial sensors called accelerometers to detect when the device is moving to measure steps. Some wrist actions can mimic the movement of a step and falsely record steps, so as with any smartwatch or tracker, the step count recorded each day should be used as a guide only.

WATER RESISTANCE HARRY LIME smartwatches are tested to IP68 standards. This guarantees water resistance for 30 minutes up to a maximum water depth of 1.5 meters. We do not recommend our watches for use in saltwater. Always rinse your smartwatch after

PRIVACY POLICY Please visit shopharrylime.com/pages/privacy-poli-

IMPORTANT SAFETY INFORMATION & WARNINGS

BATTERY WARNINGS Do not attempt to replace the battery, open the device enclosure or disassemble your HARRY LIME product. Doing so can result in a safety hazard * The integrated rechargeable battery cannot be removed or replaced * Substances within HARRY LIME smartwatch battery may harm the environment or cause injury if handled or disposed of improperly. In the unlikely event of contact with battery acid, thoroughly flush the affected area with plenty of clean water and seek IMMEDIATE medical attention * When the battery is fully charged disconnect from charger, DO NOT exceed 2 hour charge time.

charger, DO NOT exceed 2 hour charge time.

DEVICE WARNINGS Ensure your smartwatch correctly engages with the charging contacts * Before each use, please check the product for damage, do not use if the product is damaged * This is not a toy, children should not play with this product * Never attempt to open your smartwatch, this may result in danger * Protect the product for mistrong impacts, vibrations, direct sunlight and dirt * Do not place heavy objects on the product * Do not exert pressure on the product * Avoid strong magnetic fields e.g. loudspeakers * Salt and thermal water can lead to the corrosion of metal parts. Remove the product before using sunnas as the temperature difference can cause condensation * Do not operate the product are near heat sources e.g. radiators or other devices emitting heat. Do not cover the product during operation or charging * Never use the product on aeroplanes, in hospitals, service rooms, or near medical electronic systems. The wireless signals transmitted could impact the functionality of sensitive electronics * Do not use your HARRY LIME product if the display is cracked * Do not expose your HARRY LIME product to extremely high or low temperatures * Do not use abrasive cleaners to clean your HARRY LIME product * Remove your HARRY LIME product to immediately if it feels warm or hot * Do not attempt to wear or operate your HARRY LIME product fliwet * Do not theat polications on the products display while driving or in other situations where distractions could be hazardous. Always be aware of your surroundings when using

BEFORE USING THE PRODUCT, PLEASE FAMILIARISE YOURSELF WITH ALL OF THE SAFETY INFORMATION AND INSTRUCTIONS FOR USE!

HARRY LIME products and services • Ensure your smartwatch is removed at regular intervals for gentle cleaning.

HARRY LIME products and services * Ensure your smartwatch is removed at regular intervals for gentle cleaning.

HEALTH WARNINGS HARRY LIME smartwatches contain components that emit electromagnetic fields, with some of the models containing a magnetic charging dock, please be caware that these models contain magnets. These electromagnetic fields and magnets may interfere with medical devices, such as pacemakers and implanted defibrillators. Please consult your doctor and medical device manufacturer if you use any medical device before using a HARRY LIME smartwatch * This is a Class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures * The HARRY LIME heart rate monitor is designed for recreational use only, it is not intended for any medical uses such as diagnosing or monitoring any medical conditions * The HARRY LIME heart rate monitor periodically emits flashing lights, please consult your doctor before use if you have epilepsy or similar conditions * The HARRY LIME heart rate monitor usually provides an accurate estimate of your heart rate, but the reading can be affected by factors such as fit of the smartwatch, the physical characteristics of the wearer and the intensity of the activity * Your HARRY LIME smartwatch will help calculate distances covered and calories burned during training. Please consult a doctor before starting new exercise regimes * HARRY LIME smartwatches contain sensors to track your movement to closely estimate your activity, seeps calories used etc. These close estimations are not always fully accurate * Some wearers may suffer skin irritation if the smartwatch is removed regularly for cleaning 6 do not over-tighten on your wrist * We recommend you remove your smartwatch each day for gentle cleaning.

In the case of material damage or personal injury caused by incorrect

In the case of material damage or personal injury caused by incorrect handling or non-compliance with the safety instructions, no liability can be accepted by HARRY LIME. If you have any questions or concerns, please contact us.

DISPOSAL OF GOODS

The crossed out wheelie bin symbol is to remind you that waste electrical products, batteries θ accumulators should not be disposed of in household waste. If you are unable to reuse or recycle your article it should be disposed of at a civic amenity site or a local authority recycling facility.

- Do not dispose of your HARRY LIME product within household waste.
 Disposal of the packaging θ your HARRY LIME product should be done in accordance with local regulations.
 Batteries are not to be disposed of in municipal waste θ require separate collection.

Manufactured by: Peers Hardy UK Ltd, Precision House, Starley Way, Birmingham Business Park, Bickenhill Lane, Solihull, 837 7GN, UK. EU. Address, Peers Hardy UK LTD, C/O Global E-commerce Experts, Rijnlanderweg 766, Unit H, 2132 NM, Hoofddorp, Netherlands.







HARRY LIME

(+44 (0) 121 524 1400

INSTALLING THE HARRY LIME APP

Please download our smartphone App. There are a couple of ways to do this:

Search for the 'HARRY LIME' App. or,

Scan the QR code below using your smartphone camera or a OR code reader App. This will take you directly to our App ready to download



Once you open the App you'll be guided through set up.



to your smartphone, please go to SETTINGS within your app. menu, select FIRMWARE UPDATE to ensure you have the latest version of our firmware, if not, please select and install to update to the latest version.

CHARGING GUIDE

1. Line up the 2 magnetic pins on your charger head to the charging spots on the back of your smartwatch. The magnetic pins will secure the charger in place during charging.

2. Plug in the USB cable to a power source. Once connected, the charging icon will appear on screen. Please charge your watch when the screen displays low battery. Do not exceed a 2 hour charge time.



Scan the QR code to go directly to our support section.

