


Kensington - Dressing Table & Stool

Assembly Instructions - Please keep for future reference

411/5290

428/7070



Dresser Dimensions

Width - 119.9cm

Depth - 39.4cm

Height - 76.1cm

Stool Dimensions

Width - 43cm

Depth - 35.5cm

Height - 48cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 37kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Parts of the assembly will be easier with 2 people.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the overbalance protector kit supplied or, an alternative fixing method of your choice.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels


If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.


For any other queries please contact the Customer Helpline on: 0345 640 2020

Please check you have all the panels listed below


Dressing Table



1 Left Side (DF4477)
(74.6 x 37.4cm)



2 Right Side (DF2405)
(74.6 x 37.4cm)



3 Fly End (DF3472)
(74.6 x 37.4cm)




4 Modesty (DF3473)
(69.1 x 21.5cm) x 2



5 Rail (DF2383)
(42.3 x 9.2cm) x 5




6 Front Plinth (DF2385)
(48.5 x 9.2cm)




8 Top (DF3471)
(119.9 x 39.4cm)



7 Side Plinth (DF2386)
(37.4 x 9.1cm) x 2




9 Drawer Front (DF2384)
(41.7 x 19.2cm) x 3



10 Left Drawer Side (W330-124LH)
(33 x 12.4cm) x 3




11 Right Drawer Side (W330-124RH)
(33 x 12.4cm) x 3



12 Drawer Back (W390-124)
(39 x 12.4cm) x 3




13 Drawer Base (T401-327)
(40.1 x 32.7cm) x 3




14 Back (X667-449)
(66.7 x 44.9cm)

Stool



15 Stool Side (D0996A)
(451 x 352mm) x 2



16 Stool Base (D0997A)
(400 x 348mm)



17 Stool Rail (D0998A)
(400 x 144mm) x 2



18 Seat Pad (FMANPAD)
(398 x 348mm)



Components - Fittings





If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.


For any other queries please contact the Customer Helpline on: 0345 640 2020

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Metal dowel (F901) x 44</p>	<p>B </p> <p>Large locking nut (F900) x 38</p>	<p>C </p> <p>Small locking nut (F3) x 6</p>
<p>D </p> <p>Wooden dowel (F22) x 24</p>	<p>E </p> <p>Knock-in Peg (F1716Y) x 12</p>	<p>F </p> <p>38mm Screw (F81) x 4</p>
<p>G </p> <p>25mm Screw (F50) x 4</p>	<p>H </p> <p>19mm Screw (F461) x 3</p>	<p>I </p> <p>9mm Screw (F74) x 6</p>
<p>J </p> <p>9mm Screw (F73) x 12</p>	<p>K </p> <p>Wedgefix (F639) x 6</p>	<p>L </p> <p>Plastic Nail (F91) x 10</p>
<p>M </p> <p>Drawer runner (F1004) x 6</p>		<p>N </p> <p>Nail (F51) x 14</p>
<p>O   Screw  Washer x 2</p> <p>Overbalance protector kit (F269) x 1</p>		<p>P </p> <p>Handle (F220) x 3</p>

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


If you have damaged or missing components, call the
Customer Helpline: 03456 400800 quoting the reference
numbers below

Step 1

Prepare the 3 drawer fronts

Screw 2 metal dowels **A** into each of the drawer fronts **9**.

Note: Tighten the metal dowels up fully against the panels.




Step 2

Prepare the drawer sides

Insert a small locking nut **C** into the hole shown on the left drawer side **10** and the right drawer side **11**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.




Step 3

Attach the drawer sides to the drawer fronts

Push the left drawer sides **10** and right drawer sides **11** onto the back of the drawer fronts **9**.

Turn the small locking nuts **C** on the left drawer side **10** and right drawer side **11**.

Note: Turn the locking nuts **C** clockwise to secure panels - more than 1/2 a turn.




Assembly Instructions

Step 4

Fit the drawer base

Slide the drawer base **13** down the grooves in the drawer sides **10** and **11** and down into the groove in the drawer front **9**.




Step 5

Fit the drawer back

Fit the drawer back **12** between the drawer sides **10** and **11**. Make sure that the drawer base **13** fits into the groove in the drawer back **12**.


Hold the drawer back **12** in position and tap the knock-in pegs **E** through the holes in the drawer sides **10** and **11**.



Step 6

Attach the handles


Attach a handle **P** to each of the drawer fronts **9** using screw **H**.



Step 7

Fit the wedgifixes

Turn the drawer assemblies over and slide 2 wedgifixes **K** into the front and back grooves, as shown, and tighten up the screws.



Assembly Instructions

Step 8

Prepare the left side

a: Place 3 runners **M** on the left side **1** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **J**.

b: Slide the runner **M** back the other way and fit the 2nd screw **J** into the corresponding hole in the left side **1**.

c: Screw 5 metal dowels **A** into the left side **1**.

Insert 2 large locking nuts **B** into the left side **1**.






Note: The arrow on the locking nuts **must** point towards the hole in the edge of the panel.

Tap 2 wooden dowels **D** into the left side **1**.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.

Turn the left side over

d: Screw 4 metal dowels **A** into the left side **1**.



Assembly Instructions

Step 9

Prepare the right side





a: Place 3 runners **M** on the right side **2** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **J**.

b: Slide the runner **M** back the other way and fit the 2nd screw **J** into the corresponding hole in the right side **2**.

c: Screw 5 metal dowels **A** into the right side **2**.

Insert 2 large locking nuts **B** into the right side **2**.

Tap 2 wooden dowels **D** into the right side **2**.




Assembly Instructions

Step 10

Prepare the 5 rails

Insert 2 large locking nuts **B** into each of the 5 rails **5**.

Tap 2 wooden dowels **D** into each of the 5 rails **5**.




Step 11

Fit 3 of the rails to the right side

Push 3 rails **5** onto the right side **2**.

Use a screwdriver to tighten the large locking nut **B** fitted to each of the rails **5**.

Note: Turn the large locking nuts **B** as far as they will go - more than 1/2 a turn.




Step 12

Fit the other 2 rails to the right side

Push the 2 rails **5** onto the right side **2**.

Use a screwdriver to tighten the large locking nut **B** fitted to each of the rails **5**.



Note: Fit the rail at the back last and support it until the left side has been fitted in the next step.


Assembly Instructions

Step 13

Fit the left side

Push the left side **1** onto the rails **5**.


Use a screwdriver to tighten the large locking nut **B** fitted to each of the rails **5**.



Step 14

Fit the 4 plastic nails

Tap 2 plastic nails **L** into the bottom edge of each of the sides **1** and **2**.




Step 15

Prepare a side plinth

Insert a large locking nut **B** into 1 of the side plinths **7**.

Tap a wooden dowel **D** into the side plinth **7**.




Step 16

Prepare the other side plinth

Insert a large locking nut **B** into the side plinth **7**.

Tap a wooden dowel **D** into the side plinth **7**.




Assembly Instructions

Step 17

Prepare the front plinth

Screw 2 metal dowels **A** into the front plinth **6**.




Step 18

Fit the plinths together

Push the 2 side plinths **7** onto the front plinth **6**.

Use a screwdriver to tighten the large locking nuts **B** fitted to the side plinths **7**.




Step 19

Fit the plinths

Position the 3 plinths onto the assembly ensuring that the bottom edge of the plinths are flush with the bottom edge of the sides, as shown.

Secure the 2 side plinths **7** through the left end **1** and right end **2** using screws **G**.

Note: To make it easier to fit the top and plinths, place polystyrene blocks from the packaging underneath both side panels to raise the assembly.




Assembly Instructions

Step 20

Prepare the 2 modesty panels

Insert 4 large locking nuts **B** into each of the 2 modesty panels **4**.




Step 21

Prepare the fly end

Screw 4 metal dowels **A** into the fly end **3**.

Insert 2 large locking nuts **B** into the fly end **3**.

Tap 2 wooden dowels **D** into the fly end **3**.




Step 22

Fit the 2 modesty panels

Push the 2 modesty panels **4** onto the left side **1**.

Use a screwdriver to tighten the 2 large locking nuts **B** fitted to each modesty **4**.

Note: Support the modesty panels until the fly end has been fitted in the next step.



Important:
The finished edges on the modesty panels must be facing each other

Assembly Instructions

Step 23


Fit the fly end

Push the fly end **3** onto the 2 modest panels **4**.

Use a screwdriver to tighten the 2 large locking nuts **B** fitted to each modesty **4**.

Tap 2 plastic nails **L** into the bottom edge of the fly end **3**.


Note: Place 2 more polystyrene blocks from the packaging underneath the fly end.



Step 24

Prepare the top

Screw 6 metal dowels **A** into the top **8**.




Assembly Instructions

Step 25

Fit the top

Push the top **8** onto the assembly.

Use a screwdriver to tighten the 2 large locking nuts **B** fitted to each of the sides **1** and **2** and the fly end **3**.



Step 26

Fit the back

a: Square up the unit by making sure that measurement **x** to **x** equals **y** to **y**.

b: Place the back **14** onto the unit.

Nail **N** around the outside edges of the back **14**.


Note: Nails should be spaced about 150mm apart.

Carefully stand the unit up for the next step.



Warning: The unit is heavy. Lift with care.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y



Assembly Instructions

Step 27



Fit the drawers

Starting with the bottom drawer, slide both the runners **M** forward and locate the drawer sides **10** and **11** between them, lining up the holes in the drawer wrap with the 2nd 'threaded' holes in the runners **M**.

Working from the inside of the drawer, insert 2 screws **I** through the drawer sides and out into the 2nd threaded hole in the runner.

Note: Do not overtighten the screws **I**. If they catch on the runner you may need to loosen them slightly.

The assembly of the dressing table is complete




Assembly Instructions

Step 28

Prepare the 2 stool sides

Screw 6 metal dowels **B** into each of the 2 stool sides **15**, as shown.




Step 29

Prepare the stool base

Insert 4 large locking nuts **B** into the holes in the stool base **16**.

Tap 2 wooden dowels **D** into the ends of the stool base **16**.




Step 30

Fit a stool side to the stool base

Fit one of the stool sides **15** to the stool base **16**.

Use a screwdriver to tighten the 2 large locking nuts **B** fitted to the stool base **16**.




Step 31

Prepare the 2 stool rails

Insert 4 large locking nuts **B** into each of the 2 stool rails **17**.

Tap 2 wooden dowels **D** into each stool rail **17**.




Assembly Instructions

Step 32

Fit the 2 stool rails

Push the 2 stool rails **17** down onto the stool side **15**, as shown.

Use a screwdriver to tighten the 2 large locking nuts **B** fitted to each stool rail **17**.



Step 33


Fit the other stool side

a: Push the other stool side **15** down onto the assembly, as shown.


Use a screwdriver to tighten the 2 large locking nuts **B** fitted to the stool base **16**.

b: Use a screwdriver to tighten the 2 large locking nuts **B** fitted to each of the stool rails **17**.

a:



b:



Assembly Instructions


Step 34

Fit the seat pad

Position the seat pad **18** onto the assembly and make sure that its 4 edges line up with the stool base **16**.

Hold the seat pad **18** in position and screw up through the 4 holes in the stool base **16** using screws **F**.


Note: Make sure that you screw into the hard surface of the seat pad.



Step 35

Fit the plastic nails

Tap 2 plastic nails **L** into the bottom edge of each of the stool sides **15** as shown.



Assembly Instructions

Step 36

Fit the overbalance protector kit



To prevent possible overbalancing we recommend that the dressing table is secured to a suitable wall by fitting of the overbalance protector kit  to the unit, or an alternative fixing method of your choice.

Wall fixings are not supplied as they will need to suit the wall type.

Note: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.

Assembly is complete

Example



If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)
Alternatively, call the Spares Helpline on: 0370 112 1928.
For any other queries please contact the Customer Helpline on: 0345 640 2020

