


# 4564535 Luxe Chrome Glass Table Lamp

Assembly Instructions - Please retain for future reference



1

If you require any further assistance, you can contact us on 0345 640 2020 or visit [argos.co.uk](http://argos.co.uk)  
Produced in China. Sainsbury's Supermarkets, EC1N 2HT, UK. Sainsbury's (N.I.) Ltd,  
Forests Shopping Centre, Upper Galwally, Belfast, BT8 6FX, UK.

HOME

# Components & Fittings

Please check you have all the components and fittings listed below

Before commencing assembly, please identify all components.

Do not discard the packaging, until the units is fully assembled to ensure that no fittings or components are disposed of.

## Specification

Product: Luxe Chrome Glass Table Lamp

Voltage: 220-240V AC 50Hz

Wattage: Max 7W LED

Bulb Type: G9





4564635



## Bulb not included

Please turn off the power supply when replacing the bulb.

## Components





# Installation instructions

**Important** – Please retain for future reference

This product is designed for indoor use.

Do not use polish or abrasive cleaner-just a soft dry cloth.



# Safety Information

**Important** – Please retain for future reference



This product is double insulated and must not be earthed. If in doubt, we recommend you consult a qualified electrician.

This product is supplied complete with a 3-amp fuse plug. Our products should not be modified. If any modification is made, including tampering with the plug, it will invalidate the warranty and may render the product unsafe.

**IMPORTANT** - Dispose of all packaging correctly and responsibly and in accordance with all local laws and regulations. Never leave packaging components within reach of children as they can be a source of danger.

**IMPORTANT** - Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Never exceed the wattage stated.

**IMPORTANT** - When changing the bulb, always switch off at the mains and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.

**IMPORTANT** - The luminaire is designed for indoor use only.

**IMPORTANT** - This fitting is Class II appliance.

**IMPORTANT** - If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacture or his service agent or a similar qualified person in order to avoid a hazard.

THIS PRODUCT CAN GET EXTREMELY HOT DURING USE. CAUTION MUST BE TAKEN WHEN MAINTAINING, ADJUSTING OR CLEANING THE LUMINAIRE.

## BULB REPLACEMENT

1. Switch off the mains power supply.
2. Before replacing the bulb, allow it to cool down for at least 10 minutes.
3. Never touch the bulb with your fingers directly, cover it with a cloth.
4. Loosen the bulb and remove it from the lamp.
5. Replace a new bulb with same voltage and wattage



Disposal of Waste Equipment by Users in the European Union.

This symbol on the product indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resource that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your households waste disposal service or the shop where you purchased the product.

