


BUTTON OPERATION

E: BACKLIGHT

M: MODE

D: START/STOP

S: LAP/RESET



SETTING SEQUENCE

A) NORMAL TIME SETTING

- 1) IN NORMAL TIME READ-OUT PRESS "M" 3 TIMES TO GET NORMAL TIME SETTING MODE. "SEC" WILL START FLASHING. PRESS "D" FOR SYNCHRONISATION.
- 2) PRESS "S" ONCE: "HOUR" FLASHING. PRESS "D" TO ADVANCE. ("A" IS AM) ("P" IS PM) ("12" IS FOR 24HR FORMAT).
- 3) PRESS "S" ONCE: "M" FLASHING. PRESS "D" TO ADVANCE.
- 4) PRESS "S" ONCE: "DAY OF WEEK" FLASHING. PRESS "D" TO ADVANCE.
- 5) PRESS "S" ONCE: "DATE" FLASHING. PRESS "D" TO ADVANCE.
- 6) PRESS "S" ONCE: "DAY OF WEEK" FLASHING. PRESS "D" TO ADVANCE.
- 7) PRESS "M" ONCE: SETTING COMPLETED. RETURN TO NORMAL TIME READOUT.

B) ALARM TIME SETTING

- 1) IN NORMAL TIME READ-OUT PRESS "M" ONCE THEN
- 2) PRESS "S" ONCE. ALARM TIME "MIN" FLASHING. PRESS "D"
- 3) PRESS "M" ONCE. SETTING COMPLETED. RETURN TO NORMAL TIME READOUT.

C) ALARM FUNCTION AND CHIME FUNCTION

- 1) IN ALARM TIME SETTING, THE ALARM IS ARMED AND CHIME ACTIVATED BY PRESSING "D". ALM MARK AND SIG MARK APPEAR WHEN THE ALARM AND CHIME FUNCTIONS ARE ENABLED.

D) CHRONOGRAPH

- 1) IN NORMAL TIME READ-OUT PRESS "M" TWICE TO GET INTO "CHRONO" MODE. PRESS "D" TO START TIMING.

TWO OPTIONS FOR "CHRONO" MODE.

- i) DURING TIMING PRESS "D" TO STOP, AND THEN "S" TO RESET THE TIME.

OR

- ii) DURING TIMING PRESS "S" TO ENTER LAP-TIME MODE. THE ELAPSED TIME IS NOW SHOWN ON SCREEN. WHILST THE TIME CONTINUES UNTIL COMPLETED BY PRESSING "D". THEN PRESSING "S" TWICE.

INSTRUCTION MANUAL