

DURAMO / FURANO / URAHA / PARUKO QFL312BA / QFL259BB / QFL235FA / QFL311BA


TIME MODE

1. Press B to change modes.
2. Press A for EL.
3. Press C to select 12/24 hour format.
4. Press D to enable/disable hourly chime.



TIME SETTING

1. In time mode, press and hold A for 2 seconds to enter time setting.
2. Press C to increase setting value. Press D to decrease setting value.
3. Press B to enter next setting field.
4. Press pusher A to exit setting mode.




ALARM MODE

1. Press B to enter alarm mode.
2. Press A for EL.
3. Press C to select alarm 1 or alarm 2.
4. Press D to enable/disable alarm.

ALARM SETTING

1. Press and hold A for 2 seconds to enter alarm setting.
2. Press C to increase setting value. Press D to decrease setting value.
3. Press B to enter next setting field.
4. Repeat steps 2 and 3 until desired time is selected.
5. Press A to exit setting mode.

NOTE: Alarm turns on automatically when exiting setting mode.



CHRONO MODE

1. Press B to enter chrono mode.
2. Press C to start chrono.
3. Press D to stop chrono.
4. Press and hold D for 2 seconds to reset chrono.

NOTE: Maximum chrono time is 23 hours, 59 minutes, and 59 seconds. When chrono reaches maximum time, it will stop running. Press and hold D to reset value to run chrono. 1/100s resolution for first 59 minutes and 59.99 seconds.