

KT43960 MUK Rev 3

morphy richards®
smart ideas for your home



BRITA Filter Jug Kettle

 Please read and keep these instructions for future use



For competitions, product hints and tips
and more join us at



www.morphyrichards.co.uk/blog



www.facebook.com/morphyrichardsuk



[@loveyourmorphy](https://twitter.com/loveyourmorphy)

www.morphyrichards.com

* Register online for your 2 year guarantee. See the back of this instruction book for details (UK and Ireland customers only).

Health and Safety

The use of any electrical appliance requires the following common sense safety rules.
Please read these instructions carefully before using the product.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Keep the appliance and its cord out of reach of children.

Location

- This appliance is intended to be used in household and similar applications such as:
farm houses;
by clients in hotels, motels and other residential type environments;
bed and breakfast type environments.
It is not suitable for use in staff kitchen areas in shops, offices and other working environments.
- Always locate your appliance away from the edge of the worktop.
- Ensure that the appliance is used on a firm, flat surface.
- Do not use the appliance outdoors or near water.
- WARNING: Do not place the appliance onto a metal tray or metal surface whilst in use.

Mains cable

- Do not let the mains cable hang over the edge of the worktop where a child could reach it.
- Do not let the mains cable run across an open space e.g. between a low socket and a table.
- Do not let the mains cable run across a cooker or other hot area which might damage the cable.
- The mains cable should reach from the socket to the base unit without straining the connections.
- If the mains cable is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid a hazard.

Personal safety

- WARNING: To protect against fire, electric shock and personal injury do not immerse cord, plug and appliance in water or any other liquid.
- Always keep the top of the cordless base dry, especially around the connection area, disconnect the power supply before drying. Allow to dry thoroughly before reconnection to the power supply.
- Do not fill above the MAX mark, otherwise boiling water may be ejected.

- Always pour hot water slowly and carefully without tipping the appliance too fast to prevent splashing and spillage.
- WARNING: Do not open the lid whilst the water is boiling.
- Do not hold the switch in the on position or tamper with the switch to fix it in the on position as this may cause damage to the switch-off mechanism.
- Unplug from the outlet before cleaning.
- Allow to cool before putting on or taking off parts and before cleaning.
- Do not move the kettle while switched on.

Other safety considerations

- The use of attachments or tools not recommended or sold by Morphy Richards, may cause fire, electric shock or injury.
- The kettle is only to be used with the stand provided.
- Do not use the appliance for any use other than to boil water.
- Do not place the appliance on or near a hot gas or electric burner or in a heated oven.
- The appliance must not be on the base unit when being filled with water.
- Unplug from the outlet when not in use.
- WARNING: The appliance must not be immersed for cleaning.
- CAUTION: To prevent damage to the appliance, do not use alkaline cleaning agents when cleaning. Use a soft cloth and detergent.

Electrical requirements

Check that the voltage on the rating plate of your appliance corresponds with your house electricity supply which must be A.C. (Alternating Current).

Should the fuse in the mains plug require changing, a 13 amp BS1362 fuse must be fitted.

WARNING: This appliance must be earthed.


Product overview




Features

- | | |
|----------------------------------|--|
| (1) Lid | (9) BRITA MAXTRA Filter Cartridge
(One supplied)
(See page 5 for fitting instructions) |
| (2) Lid Release Button | (10) BRITA Hopper |
| (3) Spout | (11) BRITA Memo (Removable Filter Timer) |
| (4) Handle | (12) Start Button |
| (5) Water Level Indicator | (13) Cartridge Life Gauge |
| (6) On/Off Switch | (14) Cartridge Active Indicator Light |
| (7) 360° Cordless Base | (15) Power Connector |
| (8) Cord Storage
(underneath) | |


Using your filter kettle




Fill the kettle with water, do not fill past the MAX line. Do not fill through the Spout (3). The kettle will start filtering the water.



Place the kettle on the Cordless Base (7), and press the On/Off Switch (6). You can boil water while the kettle is still filtering the water.



When boiled, the kettle will automatically switch off. Remove from the Cordless Base (7).



Pour the water from the kettle.
CAUTION: Will be hot

Before first use

- Before using the appliance for the first time, fill with water, boil, and pour away.

Using filter cartridges

- Filtering your water improves the taste and appearance of beverages by reducing limescale, lead, chlorine and other impurities.
- The BRITA MAXTRA filter cartridge (9) offers improved filtration due to MAXTRA Technology. The natural MicroporeFilter in combination with the powerful ProtectFilter reduces chlorine and limescale for a great natural taste and further reduces metals such as lead and copper. Unique FlowControl ensures the perfect filtration time for best results.
- To ensure the water is filtered, fill through the Lid, do not fill the filter kettle through the Spout (3).

For information or advice on using BRITA MAXTRA or BRITA Memo, please call BRITA Customer Care on 0844 742 4800


When to replace the BRITA Cartridge

- This depends on water quality and the improvement required. We recommend that you change your cartridge after 4 weeks.
- The BRITA Memo on your Morphy Richards water filter kettle will remind you when to change your cartridge.
- BRITA Filter Cartridges conform to the highest quality standards. Raw materials and final products are subject to stringent internal and external controls. BRITA Filter Cartridges are steam treated. An independent institute certifies the food grade quality of BRITA water filters and cartridges.


Great taste, less waste:

The BRITA MAXTRA Filter Cartridge is 100% recyclable. Please contact BRITA customer care team for advice on recycling schemes on 0844 742 4800, or visit www.brita.co.uk/recycle



Replacing the filter cartridge




Immerse the BRITA MAXTRA Filter Cartridge (9) in water. Shake gently to remove any air bubbles.



Push the Filter Cartridge into the BRITA Hopper (10) until firmly in place. The Filter Cartridge should stay in place if the kettle is upside down.



Fill the kettle to the MAX line as normal and allow to filter through completely to flush the cartridge. Repeat twice



Your Filter Cartridge is ready for use.

BRITA Memo



- For maximum filter performance and for optimum taste, it is important to change your BRITA MAXTRA Filter Cartridge (9) regularly. BRITA recommends that you replace the cartridge every 4 weeks.

The unique BRITA Memo (11) measures the recommended time of use of your cartridge. The BRITA Memo is located on the filter kettle handle.

Setting the BRITA Memo

- To start BRITA Memo, please press and hold down the Start Button (12) until all four bars appear in the display and flash twice. The BRITA Memo is now set.
- The Cartridge Active Indicator Light (14) in the bottom right corner of the BRITA Memo indicates that it is working.

- Every week, one bar will disappear on the Cartridge Life Gauge (13) to show the remaining cartridge life. After four weeks, all four bars will disappear and a flashing arrow will indicate that the cartridge should now be changed. Insert a new cartridge according to the instructions, and reactivate the Memo by following 'Setting the BRITA Memo'.



Replacing the BRITA Memo

- The BRITA Memo (11) has a life of approximately 5 years. At the end of the BRITA Memo's life, please remember that it is a battery operated electronic device and to dispose of the BRITA Memo at an authorized recycling centre according to all applicable provisions and regulations.

- To remove the exhausted BRITA Memo, place a screwdriver in the notch next to the BRITA Memo and push it out. The battery cannot be removed from the BRITA Memo, so the whole device must be disposed of. Please note that BRITA Memo should not be removed for any other reason than to dispose of it.

WARNING: Batteries and products containing batteries must never be disposed of in fires.

- More information on the use of BRITA filter cartridges and the BRITA Memo can be found in the BRITA information guide supplied with the filter kettle.
- Telephone our replacement parts helpline for your new BRITA Memo.

Care and cleaning

- WARNING:** Always disconnect the plug from the mains and allow the appliance to cool before cleaning.
- Wipe the outside with a damp cloth.
- IMPORTANT:** Do not use abrasive cleaners on the outside of the appliance, as they may scratch the surface.

Descaling

IMPORTANT: As this appliance is fitted with a concealed element it must be descaled if necessary. The frequency of descaling depends on usage and the hardness of the water in your area.

Excessive scale can cause the appliance to switch off before boiling and may damage the element invalidating the warranty.

Remove hard scale using a proprietary descaling product suitable for stainless steel, glass or plastic.

For stainless steel kettles please follow the instructions carefully.

Alternatively use citric acid crystals (available from most pharmacies) as follows:

1. Remove the BRITA Hopper (10) from the Kettle.
2. Fill the appliance 3/4 full, boil, then unplug the appliance (remove the cordless kettle from the base unit) and stand it in an empty sink or bowl.
3. Gradually add 50g of citric acid crystals to the water, then leave the kettle to stand. Do not use a more concentrated solution.
4. As soon as the effervescence subsides, empty the appliance and rinse it thoroughly with cold water.
5. Wipe the outside of the appliance thoroughly with a damp cloth to remove all traces of acid which may damage the finish.

IMPORTANT: Ensure that the electrical connections are completely dry before using the appliance.

Contact us

Helpline

If you are having a problem with your appliance, please call our Helpline, as we are more likely to be able to help than the store you purchased the item from.

Please have the product name, model number and serial number to hand when you call to help us deal with your enquiry quicker.

UK Helpline: 0844 871 0960

IRE Helpline: 1800 409 119

Spares: 0844 873 0726

If you require assistance on using your BRITA MAXTRA filter cartridge or BRITA Memo, please call BRITA Customer Care team on the telephone number below.

BRITA Helpline: 0844 742 4800

Talk To Us

If you have any questions or comments, or want some great tips or recipe ideas to help you get the most out of your products, join us online:

Blog: www.morphyrichards.co.uk/blog

Facebook: www.facebook.com/morphyrichardsuk

Twitter: @loveyourmorphy

Website: www.morphyrichards.com

Notes

[illegible]

KT43960 MUK Rev 3 10/13

Registering your 2 year guarantee

Your standard one year guarantee is extended for an additional 12 months when you register the product within 28 days of purchase with Morphy Richards. If you do not register the product with Morphy Richards within 28 days, your product is guaranteed for 1 year. To validate your 2 year guarantee register with us online at

www.morphyrichards.co.uk

Or call our customer registration line

UK 0844 871 0962

IRE 1800 409 119

N.B. Each qualifying product needs to be registered with Morphy Richards individually.

Please note that the 2 year guarantee is only available in the UK and Ireland. Please refer to the one year guarantee for more information.

Your 1 year guarantee

It is important to retain the retailer's receipt as proof of purchase. Staple your receipt to this back cover for future reference.

Please quote the following information if the product develops a fault. These numbers can be found on the base of the product.

Model no.

Serial no.

All Morphy Richards products are individually tested before leaving the factory. In the unlikely event of any appliance proving to be faulty within 28 days of purchase, it should be returned to the place of purchase for it to be replaced.

If the fault develops after 28 days and within 12 months of original purchase, you should contact the Helpline number quoting Model number and Serial number on the product, or write to Morphy Richards at the address shown.

You may be asked to return a copy of proof of purchase.

Subject to the exclusions set out below (see Exclusions), the faulty appliance will then be repaired or replaced as appropriate and dispatched usually within 7 working days of receipt.

If, for any reason, this item is replaced or repaired during the 1 year guarantee period, the guarantee on the new item will be calculated from original purchase date. Therefore it is vital to retain your original till receipt or invoice to indicate the date of initial purchase.

To qualify for the 1 year guarantee, the appliance must have been used according to the instructions supplied. For example, crumb trays should have been emptied regularly.

Exclusions

Morphy Richards shall not be liable to replace or repair the goods under the terms of the guarantee where:

- 1 The fault has been caused or is attributable to accidental use, misuse, negligent use or used contrary to the manufacturer's recommendations or where the fault has been caused by power surges or damage caused in transit.
 - 2 The appliance has been used on a voltage supply other than that stamped on the products.
 - 3 Repairs have been attempted by persons other than our service staff (or authorised dealer).
 - 4 The appliance has been used for hire purposes or non domestic use.
 - 5 The appliance is second hand.
 - 6 Morphy Richards reserves the right not to carry out any type of servicing under the guarantee at its discretion
 - 7 Plastic filters for all Morphy Richards kettles and coffee makers are not covered by the guarantee.
 - 8 Batteries and damage from leakage are not covered by the guarantee.
- This guarantee does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This guarantee is offered as an additional benefit and does not affect your statutory rights as a consumer. Morphy Richards products are intended for household use only. See usage limitations within the location safety instructions.

Disclaimer

Morphy Richards has a policy of continuous improvement in product quality and design. The company, therefore reserves the right to change the specification of its models at any time.



For electrical products sold within the European Community. At the end of the electrical products useful life, it should not be disposed of with household waste.



Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice in your country



**IF YOU ARE HAVING A PROBLEM
WITH ONE OF OUR PRODUCTS,
CALL OUR HELPLINE:**

**UK: 0844 871 0960
EIRE: 1800 409 119
SPARES: 0844 873 0726**

morphy richards

The After Sales Division
Morphy Richards Ltd
Mexborough,
South Yorkshire,
England, S64 8AJ

www.morphyrichards.com

