

ENGLISH

ANALOG INSTRUCTIONS


Time Setting

1. Pull the crown out to position 2.
2. Turn the crown to set the hour and minute hands to the desired time.
3. Return the crown to position 1.



DATE MODELS

Do not change the date between the hours of 10pm and 2am. This is the time when the movement is in position to carry out the automatic date change, and any interference may cause damage to the movement.




Date Setting

1. Pull the crown out to position 1.
2. Turn the crown either clockwise or counter-clockwise and set the date for the previous day. The direction that moves the date varies on different watch models.

Time Setting

1. Pull crown out to position 2.
2. Turn counter-clockwise to advance the time and continue until the day changes to the present day.
3. Set to the correct time.

CASEBACK TIME SETTING




Time Setting

1. Push button to move hands.
2. Set to correct time.

2 EYE DAY/DATE MULTI-FUNCTION VX36

(1 crown)



Date Setting


1. Pull crown out to position 2.
2. Turn clockwise to advance date hand.
3. Push crown back to position 1.

Date and Time Setting

1. Pull crown out to position 3.
2. Turn clockwise to advance hour and minute hands.
*The hand showing days of the week will also move with the hour and minute hands.
Keep turning until you have reached the desired day.*

THREE EYE MULTI-FUNCTION 6P29/6P79

(1 crown)



Date Setting

1. Pull crown out to position 2.
2. Turn clockwise to advance the date hand.
3. Push crown back to position 1.

Day and Time Setting


1. Pull crown out to position 3.
2. Turn clockwise to advance hour and minute hands. *The hand showing days of the week will also move with the hour and minute hands. Keep turning until you have reached the desired day.*

24-Hour Sub-Dial Setting

The 24-hour hand moves correspondingly with the hour and minute hands. When setting the time be sure to check that the 24-hour hand is set properly.

CHRONOGRAPH STOPWATCH JS25/VD54

(with date-VD53) (1 crown/2 pushers)



Time and Date Setting

1. Before setting the time, make sure the chronograph is stopped and set to zero (12:00) position.
2. Pull crown out to position 2.
3. Turn crown clockwise until the previous day's date is displayed.
4. Pull crown out to position 3 when the second hand is at the 12:00 position.
5. Turn crown to set time.

NOTE: 24-hour hand moves correspondingly with the hour and minute hands. When setting the time be sure to check that the 24-hour hand is set properly.

6. Return crown to position 1.

NOTE: When the crown is in position 2, do not press the pushers. Otherwise the chronograph hands will move.

Chronograph

1. Press A to start/stop the chronograph.
2. Press B to reset to zero.

Split Time (VD53/VD54)



1. Press B while the chronograph is running.
2. Press B again to return to the chronograph.
3. Press A to finalize timing.
4. Press B to reset.

Chronograph Zero Reset

1. If either of the chronograph hands is not at the zero (12:00) position, pull crown out to position 3.
2. Press A to move hands clockwise; press B to move hands counter-clockwise.
3. Return crown to position 1.

CHRONOGRAPH STOPWATCH OS20/OS21

(1 crown/2 pushers)



Time Setting

1. Pull crown out to position 3. Chronograph second hand will return to "0."
Do not return the crown to position 1 while the hands are returning to "0," or else the position the hands are at when this is done will be recognized as the new "0" position.
2. Turn crown to set the desired time.
3. Return the crown to position 1.

Date Setting

1. Pull crown out to position 2.
2. Turn crown counter-clockwise until the correct date is shown in the date window.
3. Return crown to position 1.

Chronograph Zero Reset

This procedure should be performed when the chronograph second hand does not return to the "0" position after the chronograph has been reset.

1. Pull crown out to position 3.
2. Press A to set the chronograph second hand to the "0" position.
NOTE: The hands move quickly if the pushers are kept pressed.
3. Once the hand has been zeroed, reset the time and return the crown to position 1.

Do not return the crown to position 1 while the hands are returning to "0." Doing so will cause the position of the hands to be recognized as the new "0" position.

Chronograph Operation

This chronograph is able to measure and display time in 1/1 second up to maximum of 1 hour.

1. Press A to start/stop the chronograph.
2. Press B to reset the chronograph.

ANA-DIGI I – QX4-AP DMS

General Description / Features:

- TIME with 24-Hour Feature
- DUAL TIME ANA-DIGI
- ALARM with 2 alarms
- CHRONOGRAPH with stored data
- TIMER
- EL light operation



Analog Time Setting

1. Pull the crown out to position 2.
2. Turn the crown to set the hour and minute hands to the desired time.
3. Return the crown to position 1.

Digital Function/Setting

A - EL / SETTING BUTTON

- Press to illuminate the display.
- Press and hold 3 seconds to enter time setting mode.
NOTE: At any point in any setting mode, press A to exit setting mode.

B - MODE BUTTON

- In Normal Time Mode, press to scroll through various modes.
- Press and hold for 3 seconds to turn auto EL on/off.

C - ADJUST / START BUTTON

- In Normal Time Mode, press to toggle hourly chime on/off.
- Press when in setting modes to advance digits forward.
- In Chronograph Mode, press to start stopwatch function.

D - ADJUST/STOP/RESET BUTTON

- In Normal Time Mode, press to flash to Time 2; Press and hold for 3 seconds to toggle time display between Time 1/Time 2.

- Press when in setting modes to advance digits backwards.
- In Chronograph Mode, press to stop chronograph; Press and hold for 3 seconds to reset to zero.

NOTE: In any setting mode, if there is no activity for 30 seconds, all changes will be saved and the display will automatically return to display mode.

Time and Calendar Setting

1. In Normal Time Display, press and hold A button for 3 seconds to enter setting mode.
2. Press C button to advance hour digit forward; press D to advance digit backwards. Press B to set and advance to minute setting.
3. Press C button to advance minute digit forward; press D to advance digit backwards. Press B to set and advance to seconds setting.
4. Press C or D button to reset seconds to 0. Press B to set and advance to year setting.
5. Press C button to advance year digit forward; press D to advance digit backwards. Press B to set and advance to month setting.
6. Press C button to advance month digit forward; press D to advance digit backwards. Press B to set and advance to date setting.
7. Press C button to advance date digit forward; press D to advance digit backwards. Press B to set and advance to 24 hour display setting.
8. Press C or D button to change from 12 hour to 24 hour display. Press B to set and advance to date format display setting.
9. Press C or D button to change date format display setting.
10. Press B to exit setting mode.
11. To set Time 2, press and hold D 3 seconds in Normal Time Display to change to Time 2. Then use steps 1-4 to set.

NOTE: Weekday is automatically updated upon exiting setting mode.

Recall Mode

1. Press B to change to Recall Mode. If no data is stored, display will show NO DATA. If data is stored, display will show current set.
2. Press C to switch between stored data: total time, best time, average time, and

- lap (up to 100 laps).
3. Press D to display current set; press D again to switch to the next set.
 4. Press and hold D 3 seconds to delete all stored data in the current set displayed.

Alarm Mode

1. Press B to change to Alarm Mode.
2. Press C to toggle alarm on/off.
3. Press D to switch between alarm 1/alarm 2.
4. In Alarm Mode, press and hold A 3 seconds to enter setting mode.
5. Press C to advance hour digit forward; press D to advance digit backwards. Press B to save and advance to minute setting.
6. Press C to advance minute digit forward; press D to advance digit backwards. Press B to save and advance to Time selection.
7. Press C or D to change which time mode (Time 1/Time 2) the Alarm will read from.
8. Press A to exit setting mode.

NOTE: Alarm will sound for 20 seconds. Press any pusher to silence alarm.


Countdown Timer

1. Press B to change to Timer Mode.
2. Press C to start the timer; press D to stop the timer.
3. Press and hold D 3 seconds to clear the countdown and reset the timer.
4. In Timer Mode, press and hold A 3 seconds to enter timer setting mode.
5. Press C to advance hour digit forward; press D to advance digit backwards. Press B to set and advance to minute setting.
6. Press C to advance minute digit forward; press D to advance digit backwards. Press B to set and advance to seconds setting. Press B to return to hour setting if necessary.
7. Press A to exit timer setting mode.

ANA-DIGI 2 – BJ3255

General Description / Features:

ANA-DIGI
TIME
ALARM
LIGHT



Analog Time Setting

1. Pull the crown out to position 2.
2. Turn the crown to set the hour and minute hands to the desired time.
3. Return the crown to position 1.

Digital Function/Setting

A – LIGHT / SETTING BUTTON

- Press to illuminate the display.
- Press and hold 3 seconds to enter time setting mode.

B - MODE BUTTON

- In Normal Time Mode, press to scroll through various modes.

NOTE: In setting mode, if there is no activity for 30 seconds, all changes will be saved and the display will automatically return to display mode.

Time and Date Setting

1. In Normal Time Display, press and hold A button for 3 seconds to enter setting mode. Minute will begin to flash.
2. Press B button to adjust minute digit. Press A to set and advance to hour setting.
3. Press B button to adjust hour digit. Press A to set and advance to month setting.
4. Press B button to adjust month digit. Press A to set and advance to date setting.
5. Press and hold A to exit setting mode.

Alarm Mode

1. In Alarm Mode Display, press and hold A button for 3 seconds to enter setting mode. Hour will begin to flash.

2. Press B button to adjust hour digit. Press A to set and advance to minute setting.
3. Press B button to adjust minute digit. Press A to set and advance to alarm on/off selection.
4. Press B button to adjust alarm on/off. Press A to set and advance to chime on/off selection.
5. Press B button to adjust chime on/off.
6. Press and hold A to exit setting mode.

ANA-DIGI 3 - FL1331A

Normal Time Display

1. Press A or B for EL.
2. Press and hold A or B for 2 seconds to turn digital display off. Press any pusher to turn on the display when it is off.
3. Press C to toggle 12/24-hour format. Display will show "AM" or "PM" for 12-hour format.
4. Press D to change mode. Mode sequence is time, date, chronograph, alarm.

NOTE: In any setting mode, if no pusher is operated for 30 seconds, all changes will be saved and the setting will automatically return to display mode.



Time and Calendar Setting

1. In normal time display or calendar display, press and hold C for 2 seconds, year will begin flashing.
2. Press D to advance digits; press and hold D for fast advance.
3. Press C to advance to next setting value.
4. Setting sequence is: year, month, date, hour, minute, seconds.
5. Press C to exit setting mode.

NOTE: Weekday will automatically update upon exiting setting mode.

Chronograph Mode

1. Press D to change to chronograph mode.
2. Press D and hold 2 seconds to reset chronograph to zero.
3. Press C to start/stop the chronograph.
4. Press D to reset to zero.

Alarm Mode

1. Press D to change to alarm mode.
2. Press C to toggle alarm/chime on/off.
3. Alarm will sound at preset time for 20 seconds; press any pusher to silence alarm.

Alarm Setting


1. In alarm mode, press and hold C for 3 seconds; hour will begin flashing.
2. Press D to advance digit; press and hold D for fast advance.
3. Press C to set and advance to minute.
4. Press D to advance digit; press and hold D for fast advance.
5. Press C to exit setting mode.

DIGITAL LCD I – QBJ-3071

General Description / Features:

- TIME with 24-Hour Feature
- DUAL TIME
- ALARM with 4 alarms
- CHRONOGRAPH
- TIMER with free set value
- EL light operation

LCD Display



Operation Description

A - EL / SETTING BUTTON

- Press to illuminate the display.
- Press and hold to turn on/off EL LIGHT function and enter time setting mode.

B - MODE BUTTON

- In Normal Time Mode, press to scroll through various modes.

- Press to advance to the next adjustable set of digits when setting the time, date alarm, and countdown timer

C - ADJUST / RESET BUTTON

- In Normal Time Mode, press C button to turn on/off key tone function (KEY icon will appear/disappear).
- Press to reset the countdown in the chronograph or timer modes.
- Press when in setting modes to advance digits forward.

D - ADJUST/START/STOP BUTTON

- Press to start/stop the chronograph or timer modes.
- Press to reset the countdown in the chronograph or timer modes.
- Press when in setting modes to advance digits backwards.

Time / Calendar

1. In Normal Time Display, press and hold A button for 3 seconds to enter setting mode. Press C or D button to turn the auto EL light function on or off. Light will illuminate for 3 seconds when any button is pressed if function is on. Press B button to advance to Chime setting.
2. Press C or D button to turn the hourly chime on or off. "CHM" will appear on the display in Normal Time Mode when on. Press B button to advance to 12/24 hour mode.
3. Press C or D button to switch between 12 and 24 hour display modes. Press B button to advance to hour setting.
4. Press C or D button to advance hour display up or down. Press B button to advance to minute setting.
5. Press C or D button to advance minute display up or down. Press B button to advance to second setting.
6. Press C or D button to reset seconds to "00". Press B button to advance to year setting.
7. Press C or D button to advance year display up or down. Press B button to advance to month setting.

8. Press C or D button to advance month display. Press B button to advance to day setting.
9. Press C or D button to advance day display.
10. Press A button to exit setting mode at any time. If no button is pressed within 30 seconds, display will automatically return to Normal Time Display.

Dual Time

1. In Normal Time Display, press and hold D button for 3 seconds to enter Dal Time Mode. "T2" will appear on the display.
2. In Dual Time Mode, press and hold A button for 3 seconds to enter Dual Time setting mode.
3. Press C or D to advance hour display up or down. Hour will always appear in 24 hour time in Dual Time setting mode.
4. Press A button to exit Dual Time setting mode.
5. To return to Normal Time Display, press and hold D button for 3 seconds.

Chronograph

1. In Chronograph Mode, press D button to start/stop.
2. When stopped, press and hold C button for 3 seconds to reset to zero.
3. While chronograph is running, press C button to record Lap time.
4. When chronograph is stopped press A to check Lap record.
5. When chronograph is stopped, press and hold C button for 3 seconds to clear Lap record.

Timer

There are three functions in Timer Mode:

CD-STP - Timer will stop after countdown and return to preset value.

CD-REP - Timer will continue to countdown after timer expires up to 100 times.

CD-UP - Time will return to zero value after count-up is complete.

1. Press and hold A button for 3 seconds to enter Timer Mode setting.
2. Select Timer mode preference (CD-STP, CD-REP, or CD-UP) and press B to adjust timer value.

3. Press C or D to advance the timer value up or down.
4. Press A to exit Timer setting mode.

Alarm


There are four possible alarms that can run simultaneously.

1. In Alarm Mode, press D to select Alarm 1-4. In each alarm, press C button to turn on/off the alarm chime.
2. In the selected Alarm (1-4), press and hold A button for 3 seconds to enter setting mode.
3. Press C or D button to advance hour up or down. Press B button to advance to minute setting.
4. Press C or D button to advance minute up or down. Press A button to finish setting alarm.
5. When alarm sounds, press any button to turn off the chime or it will automatically turn off in 30 seconds.

DIGITAL LCD 2 – FL145GB

Real Time Display Mode

1. Press A for EL in mode.
2. Press C to toggle between Time 1 and Time 2.
3. Press and hold C to set Time 1 or Time 2 as the default timer.
4. Press D to toggle chime on/off.



Time/Calendar Setting

1. In normal time display, press and hold A to enter setting mode; chime will begin flashing.
2. Press C to increase setting value. Press D to decrease setting value.
3. Press B to set and advance to next setting value.

4. Setting sequence is chime, 12/24-hour time, hour, minute, second, year, month, date, Auto EL.
5. Press A to save data and exit setting mode.

Chronograph Mode

1. Press B to change to chronograph mode.
2. Press C to start chronograph; press D for lap when the chronograph is running.
3. Press D to change views while chronograph is running.
4. Press C to stop chronograph.

NOTE: When running, there is a maximum of 10 laps, afterward last lap will be overwritten each time additional lap is recorded.

Recall Mode

1. Press A to recall the memory when the chronograph is stopped.
2. Press A to view the next lap.
3. Press C or D to exit Recall Mode and go back to chronograph mode.

Timer Mode

1. Press B to change to timer mode.
2. Press C to start timer.
3. Press C to stop timer. Press D to reset the timer when it is stopped.

Timer Setting

1. In timer mode, press and hold A to enter setting mode; timer type will begin flashing.
2. Press C and D to select count down stop, count down repeat, or count up timer.
3. Press B to advance to next setting field.
4. Press C to decrease and D to increase.
5. Press B to set and advance to next setting value.
6. Setting sequence is timer type, hour, minute, second.
7. Press A to save data and exit setting mode.

NOTE: Alarm will sound at 2 beeps per second, and will beep for 30 seconds after timer reaches zero.


Alarm Mode

1. Press B to change to alarm mode.
2. Press C to toggle between alarms 1, 2, 3, 4.
3. Press D to enable the alarm; press D again to disable the alarm.
4. Press B to exit alarm mode.

Alarm Setting

1. In alarm mode, press and hold A to enter setting mode, hour will begin flashing.
2. Press C to increase; press D to decrease.
3. Press B to set and advance to next setting value.
4. Setting sequence is hour, minute.
5. Press A to exit setting mode.

PIN LINK DIAGRAM



Link Removal

To remove a link from a pin link bracelet, you will need the bracelet holder, pin pusher, and chain nose pliers (see pin link diagram).

1. Open the clasp on the bracelet.
2. Look on the inside of the bracelet and locate the arrows near the clasp (see diagram).
3. Place the band into the appropriate size slot of the bracelet holder with the arrows pointing down (see diagram).
4. Center the desired pin to be removed over one of the holes in the bottom of the bracelet holder.
5. With the pin pusher, push the pin, as far as possible, through the link.
6. Remove the watch from the bracelet holder and simply finish pulling out the pin with the chain nose pliers.

NOTE: Two pins hold each link in place and must be taken out before a link can be removed. Please note that the pins are partially split down the center.

USE PRECAUTIONS - RESISTANCE TO WATER

All Armani Exchange timepieces are designed to withstand use as indicated on line 1 of the following chart.

Indication		Water-related Use			
	Water-resistant characteristics	Light spray perspiration, light rain, etc.	Bathing, etc.	Swimming, etc.	Skin diving (Diving without oxygen cylinder)
1	3 ATM	OK	NO	NO	NO
2	5 ATM	OK	OK	NO	NO
3	10 ATM	OK	OK	OK	NO
4	20 ATM	OK	OK	OK	OK

Always set the crown in the normal position. Tighten screwlock crown completely.