ᠵ**ᡅ**᠊ᠷᢄᠼᢄᢑᠼ᠖

EARNSHAW

London

INSTRUCTION MANUAL



╘╪╔╪╔

-1805-

EARNSHAW

London

Congratulations on your purchase of this finely crafted Earnshaw Timepiece.

You are now the owner of a timepiece that draws its roots from the renowned English horologist, clock and watch maker Thomas Earnshaw 1749 - 1829

MECHANICAL AUTOMATIC 3 HANDS

This timepiece is equipped with a self-winding Mechanical Automatic movement. It does not need a battery. It is powered by the motions of the user's own wrist during the wear of the watch. You may also choose to wind the watch manually.

For more details on operating this timepiece please refer to the enclosed booklet or visit :

IM.THOMAS-EARNSHAW.COM

A) DISPLAY



PLEASE READ THE FOLLOWING BEFORE UNSCREWING THE CROWN:

SCREW-DOWN CROWN

Screw-down crowns are used to ensure water resistance. ALWAYS be certain that your crown is securely screwed down (Position 0 is secured. Positions 1 and 2 are not secured for water resistance).

Do NOT unscrew your crown while you are in any environment where moisture is present.



B) USING THE SCREW-DOWN CROWN

DO NOT PULL THE CROWN UNLESS IT IS UNSCREWED FIRST:



TO UNSCREW: Turn the crown anti-clockwise until it turns freely without tension. GENTLY pull the crown out to the other desired positions for watch setting (see specific operating instructions on the following pages).



TO SCREW: Push the crown ALL THE WAY IN (towards the watch) THEN begin to turn clockwise until it is securely screwed down.

NOTE: Failure to SECURELY screw down the crown after setting the watch may affect its water resistance.

BEFORE YOU USE THIS WATCH, IT IS RECOMMENDED THAT YOU MANUALLY WIND THE MAINSPRING TO START IT MOVING.

This watch is an automatic watch equipped with a manual winding mechanism.

WINDING THE MAINSPRING



1. Unscrew the crown by turning it anti-clockwise.



 When it is in position 1, turn the crown clockwise to wind. Wind 5-10 times and it will start to move naturally after shaking slightly.



3. Push the crown in then screw it securely.

NOTE:

This watch MUST be worn for at least 8 (Eight) hours each day to ensure it is fully wound.

An automatic watch will only wind when the watch is on your wrist and your arm moves.

Winding the watch by the crown will put power on the spring but not enough to allow the watch to function fully. If your watch stops overnight or loses time it means it is not being fully wound.

C) TIME SETTING

- 1. Pull the crown to position 2.
- 2. Turn the crown to set Hour and Minute hands.
- 3. Push the crown back to position 0.



WATER RESISTANCE

The water resistance indicated on your timepiece serves only as a guide. Actual water resistance may vary depending on a number of important factors including temperature, water salinity, and actual use under water.

The water resistance of your timepiece may eventually be compromised over time with general wear and tear and the use of your watch under adverse conditions.

Always remember to employ the screw down crown (if available) to maintain the water resistance of your timepiece. Warranty may be voided if the screw down crown has not been properly employed. 7

6

Note that you should **NEVER** wear your watch in a jacuzzi, hot shower or steam room where steam may enter the case despite the watertight seals used to protect your watch.

The steam may cause condensation inside your watch, which may affect and damage the inner workings of your watch – which would also not be covered by the warranty.