

Instruction Manual

- In the normal display shows hours, minutes, seconds, Days of the week.
- Chronograph function.
- 20 seconds alarm function.
- Selectable 12/24 hour clock.
- EL back light
- Hourly Chime
- 3V Lithium battery - CR2016,

How to set the time

- In normal time display, press button "A" three times
- The seconds will flash
- Press button "B" the reset second to zero
- Press button "C", hour will flash
- Press button "B" to adjust
 - 12hr format: A=am P=pm displayed
 - 24hr format will not display A or P
- Press button "C", minute will flash
- Press button "B" to adjust
- Press button "C", month will flash
- Press button "B" to adjust
- Press button "C", date will flash
- Press button "B" to adjust
- Press button "C", day will flash
- Press button "B" to adjust
- Press button "A" to confirm and accept changes.

Alarm and chime

- To switch ON alarm and chime
- Press button "A" Twice
- Press button "B" "ALM" (alarm on) displayed
- Press button "B", "CHM" displayed (chime on) "ALM disappear (alarm off)
- Press button "B", "CHM" and "ALM" displayed (alarm and chime on)
- Press button "A" to confirm setting and display normal time

- To switch OFF alarm and chime
- Press button "A" twice to enter alarm mode
- Press button "B", "CHM and ALM" disappear. Alarm and chime off

How to set alarm

- In normal time press button "A" twice to enter alarm mode

- Press button “C” hour flashing and “ALM” displayed (alarm on)
- Press button “B” to adjust
- Press button “C” minute flashing
- Press button “B” to adjust
- Press button “C” to accept changes
- Press button “A” to show normal time

How to use stop watch

- In normal time press button “A” once to enter chronograph mode
- Press button “B” to start
- Press button “B” again to stop
- Press button “C” to reset

Lap time operation

- When chronograph is running press button “C” to measure lap “SP” displayed
- Press button “C” again to return to the count
- Press button “B” to stop the time at the end of the event
- Press button “C” to reset
- Press button “A” to return to normal time

How to use light

- In normal time press button “D”
- To change color of the light – press and hold button “D” for 2 seconds

Stopwatch setting

1. Press A button once
2. Press B button to start and pause
3. Press C button to reset seconds to “00”
4. Press A button to return to normal mode

Alarm setting

1. Press A button twice
2. Press B button to check whether the alarm and chime function are on
3. Press C button, the hour digits will flash, press B button to set hour
4. Press C button to switch to minute digits, press B button to set minute

5. Press A button to return to normal mode

Time setting

1. Press A button for three times, the second digits will flash
2. Press B button to reset second to "00"
3. Press C button to switch to hour digits, press B button to set hour
4. Press C button to switch to minute digits, press B button to set minute
5. Press C button to switch to month, press B button to set month
6. Press C button to switch to date, press B button to set date
7. Press C button to switch to week, press B button to set week
8. Press A button to return to normal mode

Night Light

1. Press D button to turn on the light for 3 seconds
- ** Please change the battery if its display was blurred.