





# ALARM WATCH INSTRUCTION MANUAL

## General Operation/ Functions 6 Digitals LCD Electronic Alarm Chronograph Watch

### Features:

- Electroluminescent Glo Light for night viewing
- Month/ Date/ Day/ Weekday Display
- Hours/ Minutes/ Second display
- Daily Alarm
- 12/24 Hour Format

### Normal Time Mode:



### Normal Time Reading

Hour/ Minutes/ Second/ Weekday

- S1 Button- Show Month/ Day/ Weekday
- S2 Button- Show Alarm Time
- S3 Button- Show Mode(function)
- S4 Button- Show Glo Light

### Alarm

In Normal Time Mode Press and hold S2 (the display will show the alarm time in hour and minute)

- Press S1 Alarm Bell will be on or off
- Release S2 to Normal Time

### Hourly Chime

In Normal Time Mode Press and hold S2 (the display will show the alarm time in hour and minutes)

- Press S3 - hourly chime on (indicated with all of the day showing)
- Press S3 hourly chime off - No "day flag" showing

### Chronograph Mode

In Normal Time Mode press S3 once. You are now in Chronograph Mode. Operate the chronograph:

- By pressing S1 to start and stop
- By pressing S2 to reset to zero (when: chronograph is stopped)
- By pressing S3 will return to Normal Time Mode

### Lap Time Operation

In Normal Time Mode press S3 once entering Chronograph Mode.

Start the chronograph:

- By pressing S1 to start
- By pressing S2 to measure splits or laps
- By pressing S2 to restart the count
- By pressing S1 to stop at end of the event
- By pressing S2 to reset to zero (when: chronograph is stopped)
- By pressing S3 will return to Normal Mode

### Normal Time Setting

In Normal Time Mode by pressing S3 three (3) times, the seconds digits will flash. Press S1 to set the seconds to zero. Then select the Setting Modes S2 and advance by S1 with the procedures as Following:

- 1st Press - Set the Minute      • 2nd Press - Set the Hour
- 3rd Press - Set the Date        • 4th Press - Set the Month
- 5th Press - Set the Weekday
- Press S3 will return to Normal Time Mode

### Alarm Time Setting

In Normal Time Mode press S3 Two (2) times. Alarm hour digit will start flashing. Advance hour by pressing S1. Press S2 minute digit will be flashing. Advance by pressing S1. Press S3 to return to Normal Time Mode.

### 12 or 24 Hours Time Option

In Normal Time Mode press S3 three (3) times. second digit will flash. Then press S2 two (2) times hour digit will flash, then press S1 and hour will advance in the following format:

- A = AM
- P = PM
- H = 24Hours Time

Pressing S3 will return to Normal Time Mode.

### Alarm Sound Test

In Normal Time Mode depress S1 and S2 at the same time

### Alarm Sound Off

Press S2 to stop alarm sound