

SAFETY GUIDELINES

Not suitable for children under three years, contains small parts.

This equipment must be assembled and checked by an adult. Two adults may be required to assemble this product. For family domestic use only. This product has not been designed for commercial use in play centers, nurseries etc. Adult supervision is required at all times.

Only one child per seat at any one time.

The item is not designed for adults or for children weighing more than 45kg.

For outdoor use.

Check all nuts, bolts and fittings for tightness and tighten if required.

Check all coverings for bolts and sharp edges and replace when required.

Check swing seats, chain, ropes and other means of attachments if relevant to your product for evidence of deterioration. Replace when required in accordance with the manufacturers instructions if necessary.

Place the product on level surface at least 2 metres from any structure or obstruction such as a fence, garage, house,

wall, overhanging branches, laundry line or electrical wires. The items MUST be anchored firmly into the ground.

DO NOT install the product over concrete, asphalt or any hard surface.

DO NOT orientate the product directly towards the sun.

Leave all fittings finger tight until assembly is complete, for ease of construction. Then tighten firmly.

Children should not wear cycle helmets whilst on this equipment.

Do not allow children to stand on any swing seats, glider seats or slide chutes relevant to your product.

Do not allow the children to jump or climb off any moving equipment.

Do not twist swing ropes or wrap them over the top bar.

Do not allow loose, hooded or baggy clothes to be worn as children can get trapped and may be unable to free themselves.

Do not allow children to climb on parts of this equipment intended for this purpose.

Do not allow children to wander into the play area whilst the equipment is in use.

Gliders and swings must not exceed an angle of 60 degrees from the ground.

Regularly check the item for wear and damage, removing the item from use when necessary until replacement parts are fitted.


Failure to assemble and maintain this item as per instruction may cause injury to the user.

Please keep the instructions in a safe place for future reference.


Made in China to European Standards.


Conforms to EN71


SWING PARTS LIST




IMPORTANT: Make sure you read the safety notice on the front page and always supervise children while they are playing on the equipment. Once assembly is completed carefully check equipment. In the unlikely event that you do find any problems, please contact us. Do not allow children to use this product until the problem has been corrected.











- Remember to attach the rope clamp to the $\mbox{\bf U}$ bolt












• Assemble seats (11) and attach to seat tubes (10) before tightening bolts (G4)

STEP 3 Anchoring the Gym to the ground

IMPORTANT: For safety reasons this gym MUST be anchored into the ground. We recommend that it is concreted in. If you are uncertain about this procedure, telephone our helpline number.





MV Sports & Leisure Ltd. 35 Tameside Drive Castle Bromwich Birmingham B35 7AG United Kingdom email: info@mvsports.com www.mvsports.com

CUSTOMER SERVICE

MV has taken great care to ensure that this toy has reached you in good condition. Should you have a query, please contact: customer.services@mvsports.com where your query will be dealt with promotiv. Alternatively, you can call on 0870 8404255.

