


Assembly Instructions

Step 7

a: Assembly -
Parts: Foot cover x 4
Check all assembly points,
before securely fitting the
foot covers to all 4 corners
of the frame.


a: Assembly
Securing the cover.
Attach all the elastic loops
to frame legs.



Step 8

b: Please note:
To correct any wobble, tilt
the frame onto it's back,
holding the handles above
the legs, shift the alignment
slightly to the left or right.

**Please re-check all nuts
and re-tighten as
necessary.**




My First Trampoline

Assembly & User Instructions - Please keep for future reference

408/8482

425/7354



Important

**Age: 12m+
Maximum user
weight 18kg**


Important - Please read these instructions fully before starting assembly

These instructions contain important information which will help you get the best from your product and ensure safe and correct assembly, use and maintenance.

If you need help or have damaged or missing parts, call the **Customer Helpline: 0800 389 8591**

Contents

| | |
|---------------------------|-----|
| Safety Information | 2 |
| Parts | 3 |
| Assembly Instructions | 4-7 |
| Select area | 4 |
| Frame legs with mat | 4 |
| Assemble frame rear | 5 |
| Connect handles | 5 |
| Assemble frame to handles | 6 |
| Attach feet | 7 |
| Secure cover to frame | 7 |
| Adjust wobble | 7 |




Assembly Instructions

Step 5

a: Assembly -
Parts: D and E
Slot the assembled handles through the holes in the top of the mat and between the frames A and C.

a:




Step 6

b: Assembly -
Parts: A / C / D and E
Components: A x 2
Insert bolt (A) through frame (A), pole (D) and then through frame (C). Fasten frames together with the washer and dome nut from bolt (A). Repeat this sequence for the opposite side of the trampoline handle.

FULLY TIGHTEN ALL NUTS BEFORE MOVING ON TO THE NEXT STEP.

b:




Parts


If you have damaged or missing parts, call the **Customer Helpline: 0800 389 8591**

Please check you have all the fittings listed below


1 - Frame leg A x 1




2 - Frame leg B x 1



3 - Frame leg C x 2




4 - Handle frame D x 1



5 - Handle frame E x 1




6 - Mat with Cover x 1




7 - Foot cover x 4



Note: The quantities below are the correct amount to complete the assembly. In some case more fittings may be supplied than are required.




Ruler - Use this ruler to help correctly identify the fittings



Assembly Instructions


Step 1

a: Select area. Lay the frame out on the floor - refer to parts list. **Critical:** Check square holes and round holes are positioned as shown.



Step 2

b: Assembly - Insert frame legs only through the elastic loops in the mat as shown. **Critical:** Ensure frame leg 'A' is positioned on the same side as the handle holes on the mat.




Assembly Instructions

Step 3

a: Assembly -
Parts: B and C
Components: A x 2
Insert bolt (A) through frame (B) and then through frame (C).
Fasten frames together with the washer and dome nut from bolt (A).
Repeat this sequence for the opposite side of the trampoline.
LOOSELY FASTEN THE NUTS AT THIS STAGE.



a:



Step 4

b: Assembly -
Parts: D and E
Assemble the handle by fixing the handle sections together to form an arch.
Make sure the spring peg fits into the hole.

b:



WARNING: Safety Information

Important - Please read these instructions fully before starting assembly

WARNING: General safety

- The trampoline shall be assembled by an adult in accordance with the assembly instructions and thereafter checked before first use.
- Ensure bolts and small components are kept out of reach of young children.
- No modifications should be carried out to this trampoline and no accessories should be added.
- Suitable for indoor and outdoor use.
- When indoors use without shoes / When outdoors use with shoes.
- Recommended for children from 12m+
- Maximum weight of user - 18kg.
- For family domestic use only.
- Do not use the mat when it is wet.
- Do not use or leave the trampoline in wet or windy conditions.

WARNING: Positioning

- Trampoline only to be moved by an adult.
- Use in an open flat level area. If outside, use on grassed area at least 2m away from any structure or obstruction such as a fence, garage, house, overhanging, branches, laundry lines or electrical wires.
- Do not use the trampoline on concrete, asphalt or any other hard surface.
- Do not use in the same proximity of other installations such as paddling pools, swings, slides or climbing frames.
- Trampoline not design to be anchored in any such way or buried into the ground.
- If indoors, use away from furniture and other obstacles.

WARNING: Before use

- Please remove all packaging attachments before giving this product to your child.
- Check that all spring-loaded (pit-pin) joints are still intact and cannot become dislodged during play.
- Ensure pets, other children or obstructions are not hiding under the trampoline.
- Check all fixings regularly, tighten if necessary, and check that the suspension system is secure. Failure to comply with these precautions may result in injury.
- Check metal sections or components for signs of corrosion. Failure to comply with these precautions may result in injury.
- Check all coverings, padding and sharp edges for defects and replace when required.
- Discontinue use if weakening or breakage found. Contact our Customer Services Department in the event of a failure.

WARNING: During use

- Warning: Young children in play are unaware of potential dangers and hazards, therefore responsible adult supervision is essential.
- Ensure children are not wearing loose clothing that could snag on the equipment, such as baggy pockets, hoods or jewellery. Empty pockets and hands before jumping.
- Do not eat or drink while jumping.
- Do not allow your child to attempt somersaults or stunts whilst on product. Do not exit with a jump.
- Limit the time of continuous usage (make regular stops).
- Ensure your child always jumps in the middle of the mat.
- Warning: No more than 1 child at any one time. Collision hazard.

Information

- If you need help or have damaged or missing parts, call the Customer Helpline: 0800 389 8591
- Produced for Chad Valley Toys.
- Argos Ltd.
- Country of origin: Made in China.
- Address: 489 - 499 Avebury Boulevard, Central Milton Keynes, MK9 2NW. www.argos.co.uk

IMPORTANT!
RETAIN THESE INSTRUCTIONS
FOR FUTURE REFERENCE