

### G-SHOCK


#### AW-80-1A2VEF


##### Specifications

- ⇒ 100M WR
- ⇒ Daily Alarm
- ⇒ Stopwatch
- ⇒ World Time
- ⇒ LED Light
- ⇒ 30 Page Data Memo
- ⇒ 10- Year Battery



Model variations may differ in appearance from the example above.

<b>World Time</b>	Displays the current time in major cities and specific areas. Current time in 48 cities (31 time zones)	Press button <b>C</b> to enter World Time mode, your current world time city code should appear on the digital display for two seconds. Press <b>D</b> to get the next city code in order.  <b>To set the World Time</b>  <ol style="list-style-type: none"> <li>In the World Time Mode, press <b>(D)</b> to scroll through city codes.</li> <li>Hold down <b>(A)</b> until the DST On/Off setting of the world time starts to flash, which indicates the setting screen.</li> <li>Press <b>(C)</b> to move the flashing in the sequence shown below to select the other settings.</li> </ol> <p>4. While a setting is flashing, use <b>(D)</b> and <b>(B)</b> to change it.</p> <ul style="list-style-type: none"> <li>Pressing <b>(D)</b> and <b>(B)</b> at the same time while any World Time setting is flashing causes the displayed time to change to the same setting as the current Timekeeping Mode time.</li> <li>While DST On/Off setting is selected (flashing), press <b>(D)</b> to toggle between Daylight Saving Time (ON) and Standard Time (OFF).</li> <li>While the hour or minutes setting is selected (flashing), use <b>(D)</b> (+) and <b>(B)</b> (-) to change it.</li> </ul> <p>5. Press <b>(A)</b> to exit the setting screen.</p>
<b>Stop Watch</b>	Elapsed time, split time and two finishes	Press button <b>C</b> until display shows stopwatch function (STW) Start and stop the stop watch using button. Measure times:

<b>Daily Alarms</b>	<b>To Set an Alarm Press D:</b> <b>To set an alarm time</b>  <ol style="list-style-type: none"> <li>In the Alarm Mode, use <b>(D)</b> to scroll through the alarm screens until the one whose time you want to set is displayed.</li> </ol> <ul style="list-style-type: none"> <li>To set a one-time alarm, display one of the screens indicated by an alarm number AL1 or AL2. To set the snooze alarm, display the screen indicated by SNZ.</li> <li>The snooze alarm repeats every five minutes.</li> </ul> <ol style="list-style-type: none"> <li>After you select an alarm, hold down <b>(A)</b> until the hour setting of the alarm time starts to flash, which indicates the setting screen.</li> <li>This operation automatically turns on the alarm.</li> <li>Press <b>(C)</b> to move the flashing between the hour and minute settings.</li> <li>While a setting is flashing, use <b>(D)</b> (+) and <b>(B)</b> (-) to change it.</li> <li>When setting the alarm time using the 12-hour format, take care to set the time correctly as a.m. (A indicator) or p.m. (P indicator).</li> <li>Press <b>(A)</b> to exit the setting screen.</li> </ol>
---------------------	---

<b>Water Resistant</b>	Suitable for bathing, swimming, and showering. not for diving.
------------------------	--

<b>LED Light</b>	Includes an After-Glow feature that keeps the illuminator turned on for a few seconds after the light button released.	In any mode (except when setting screen is on the display) Press <b>B</b> to illuminate display
------------------	--	---

<b>10 Year Battery</b>	Battery power lasts up to approximately ten-years without changing.	CASIO's advanced technology allows extended battery life for up to ten-years . All timekeeping modes and functions of the watch can be used continuously for up to seven-years without a battery change.
------------------------	---	--